

Table of Contents

SECTION 1
(Orange Tab)

GENERAL

SECTION 2
(Orange)

LIMITATIONS

SECTION 3
(Orange)

EMERGENCY PROCEDURES

SECTION 4
(Clear)

NORMAL PROCEDURES

SECTION 5
(Clear)

PERFORMANCE

SECTION 6
(Blue)

WEIGHT AND BALANCE

SECTION 7
(Yellow)

AIRPLANE AND ITS SYSTEMS

SECTION 8
(Yellow)

HANDLING, SERVICING, MAINTENANCE

SECTION 9
(Yellow)


SUPPLEMENTS

SECTION 10
(Yellow)

OPERATING TIPS

MISC.
(Red)

A.D.'s, AVIONICS INSTRUCTIONS



**Piper Warrior
PA28-151
1976
N7963F**

PILOT'S OPERATING HANDBOOK

PIPER CHEROKEE WARRIOR



FAA APPROVED IN NORMAL AND UTILITY CATEGORIES BASED ON CAR 3 AND FAR PART 21, SUBPART J. THIS HANDBOOK INCLUDES THE MATERIAL REQUIRED TO BE FURNISHED TO THE PILOT BY CAR 3 AND FAR PART 21, SUBPART J AND CONSTITUTES THE APPROVED AIRPLANE FLIGHT MANUAL AND MUST BE CARRIED IN THE AIRPLANE AT ALL TIMES.

AIRPLANE SERIAL NO. 28-7715251

AIRPLANE REGISTRATION NO. N7963F

PA-28-151
REPORT: VB-780

FAA APPROVED BY: Ward Evans
WARD EVANS
D.O.A. NO. SO-1
PIPER AIRCRAFT CORPORATION
VERO BEACH, FLORIDA

DATE OF APPROVAL: JUNE 17, 1976



WARNING

EXTREME CARE MUST BE EXERCISED TO LIMIT THE USE OF THIS MANUAL TO APPLICABLE AIRCRAFT. THIS MANUAL REVISED AS INDICATED BELOW OR SUBSEQUENTLY REVISED IS VALID FOR USE WITH THE AIRPLANE IDENTIFIED ON THE FACE OF THE TITLE PAGE WHEN OFFICIALLY APPROVED. SUBSEQUENT REVISIONS SUPPLIED BY PIPER AIRCRAFT CORPORATION MUST BE PROPERLY INSERTED.

MODEL PA-28-151, CHEROKEE WARRIOR

PILOT'S OPERATING HANDBOOK, REPORT: VB-780 REVISION

1

PIPER AIRCRAFT CORPORATION

APPROVAL SIGNATURE AND STAMP

M. Keeler



Published by
PUBLICATIONS DEPARTMENT
Piper Aircraft Corporation
Issued: June 17, 1976

APPLICABILITY

Application of this handbook is limited to the specific Piper PA-28-151 model airplane designated by serial number and registration number on the face of the title page of this handbook.

This handbook cannot be used for operational purposes unless kept in a current status.

REVISIONS

The information compiled in the Pilot's Operating Handbook will be kept current by revisions distributed to the airplane owners.

Revision material will consist of information necessary to update the text of the present handbook and/or to add information to cover added airplane equipment.

I. Revisions

Revisions will be distributed whenever necessary as complete page replacements or additions and shall be inserted into the handbook in accordance with the instructions given below:

1. Revision pages will replace only pages with the same page number.
2. Insert all additional pages in proper numerical order within each section.
3. Page numbers followed by a small letter shall be inserted in direct sequence with the same common numbered page.

II. Identification of Revised Material

Revised text and illustrations shall be indicated by a black vertical line along the outside margin of the page, opposite revised, added or deleted material. A line along the outside margin of the page opposite the page number will indicate that an entire page was added.

Black lines will indicate only current revisions with changes and additions to or deletions of existing text and illustrations. Changes in capitalization, spelling, punctuation or the physical location of material on a page will not be identified by symbols.

ORIGINAL PAGES ISSUED

The original pages issued for this handbook prior to revision are given below:

Title, ii through v, 1-1 through 1-14, 2-1 through 2-8, 3-1 through 3-12, 4-1 through 4-16, 5-1 through 5-24, 6-1 through 6-56, 7-1 through 7-24, 8-1 through 8-16, 9-1 through 9-10, 10-1 through 10-2.

PILOT'S OPERATING HANDBOOK LOG OF REVISIONS

Current Revisions to the PA-28-151 Cherokee Warrior Pilot's Operating Handbook, REPORT: VB-780 issued June 17, 1976.

Revision Number and Code	Revised Pages	Description of Revision	FAA Approval Signature and Date
Rev. 1 - 761 623 (PR760803)	6-43	Revised items 183, 185 and 187.	<i>Ward Evans</i> Ward Evans August 3, 1976
Rev. 2 - 761 623 (PR770118)	3-4 3-11 4-5 4-7 4-8 4-14 5-11 6-4 6-5 6-35 7-13 10-1 10-2	Revised Open Door procedure. Revised para. 3.27 info. Revised Takeoff procedure. Added Caution to para. 4.9; relocated material to page 4-8. Added relocated material from page 4-7. Added Note to para. 4.31. Removed "GEAR DOWN" from Fig. 5-1. Added A & B values to Fig. 6-3. Revised weight and balance formula. Revised item 79 Arm and Moment. Revised wording in text. Revised 10.3 (c); relocated material to page 10-2. Added relocated material from page 10-1.	<i>Ward Evans</i> Ward Evans Jan. 18, 1977
Rev. 3 - 761 623 (PR770223)	1-6 3-11 4-4 4-9 6-4 7-24	Corrected to "Meteorological." Revised NOTE. Revised Starting Engine When Hot procedure. Revised 4.13 (b). Revised Leveling Diagram illustration. Added ELT test info.	<i>Ward Evans</i> Ward Evans Feb. 23, 1977

PILOT'S OPERATING HANDBOOK LOG OF REVISIONS (cont)

Revision Number and Code	Revised Pages	Description of Revision	FAA Approval Signature and Date
Rev. 5 - 761 623 (PR790216) (cont)	7-18 7-21 7-23	Revised para. 7.21. Added Caution to para. 7.23. Revised para. 7.35.	<i>Ward Evans</i> Ward Evans Feb. 16, 1979
Rev. 6 - 761 623 (PR880817)	v 1-3 1-6 1-7 2-1 2-2 3-i 3-1 4-i 4-1 4-3, 4-4, 4-5 4-7 4-8 4-11 4-12 4-16 5-1 5-3, 5-4, 5-5, 5-6 6-1 6-3 6-6 6-7 6-9, 6-10 6-11 6-12 6-17 7-12 7-22 8-1 8-3 8-4 8-11 8-12 9-5 10-i 10-1 10-2	Revised Table of Contents. Revised para. 1.7. Revised para. 1.19(b). Revised para. 1.19(e). Revised para. 2.1. Revised para. 2.7(g). Revised Table of Contents. Revised para. 3.1. Revised Table of Contents. Revised para. 4.1 and para. 4.3. Revised para. 4.5 (Normal Procedures Checklist). Revised para. 4.7 and para. 4.9. Revised para. 4.11. Revised para. 4.17 and para. 4.19. Revised para. 4.21. Revised para. 4.39. Revised para. 5.1 and para. 5.3. Revised para. 5.5 (Flight Planning Example). Revised para. 6.1. Revised para. 6.3. Revised para. 6.5. Revised Fig. 6-5. Revised Weight and Balance Record; added Title and Fig. no. Revised Fig. 6-9. Revised Fig. 6-11. Revised para. 6.9. Revised para. 7.15 (added Warning). Revised para. 7.31. Revised para. 8.1. Revised para. 8.3. Revised para. 8.5. Revised para. 8.21(b). Revised para. 8.21(d). Revised section 3, para. (a). Revised Table of Contents. Revised Title; revised para. 10.1 and para. 10.3. Revised Title.	<i>D.H. Trompler</i> D.H. Trompler Jan. 13, 1989 Date

TABLE OF CONTENTS

SECTION 1

GENERAL

Paragraph No.		Page No.
1.1	Introduction	1-1
1.3	Engines	1-3
1.5	Propellers	1-3
1.7	Fuel	1-3
1.9	Oil	1-3
1.11	Maximum Weights	1-4
1.13	Standard Airplane Weights	1-4
1.15	Baggage Space	1-4
1.17	Specific Loadings	1-4
1.19	Symbols, Abbreviations and Terminology	1-5
1.21	Conversion Factors	1-11

SECTION 1

GENERAL

1.1 INTRODUCTION


This Pilot's Operating Handbook is designed for maximum utilization as an operating guide for the pilot. It includes the material required to be furnished to the pilot by C.A.R. 3 and FAR Part 21, Subpart J. It also contains supplemental data supplied by the airplane manufacturer.

This handbook is not designed as a substitute for adequate and competent flight instruction, knowledge of current airworthiness directives, applicable federal air regulations or advisory circulars. It is not intended to be a guide for basic flight instruction or a training manual and should not be used for operational purposes unless kept in a current status.

Assurance that the airplane is in an airworthy condition is the responsibility of the owner. The pilot in command is responsible for determining that the airplane is safe for flight. The pilot is also responsible for remaining within the operating limitations as outlined by instrument markings, placards, and this handbook.

Although the arrangement of this handbook is intended to increase its in-flight capabilities, it should not be used solely as an occasional operating reference. The pilot should study the entire handbook to familiarize himself with the limitations, performance, procedures and operational handling characteristics of the airplane before flight.

The handbook has been divided into numbered (arabic) sections, each provided with a "finger-tip" tab divider for quick reference. The limitations and emergency procedures have been placed ahead of the normal procedures, performance and other sections to provide easier access to information that may be required in flight. The "Emergency Procedures" Section has been furnished with a red tab divider to present an instant reference to the section. Provisions for expansion of the handbook have been made by the deliberate omission of certain paragraph numbers, figure numbers, item numbers and pages noted as being left blank intentionally.



THREE VIEW

Figure 1-1

1.3 ENGINES

(a) Number of Engines	1
(b) Engine Manufacturer	Lycoming
(c) Engine Model Number	O-320-E3D
(d) Rated Horsepower	150
(e) Rated Speed (rpm)	2700
(f) Bore (inches)	5.125
(g) Stroke (inches)	3.875
(h) Displacement (cubic inches)	319.8
(i) Compression Ratio	7:1
(j) Engine Type	Four Cylinder, Direct Drive, Horizontally Opposed, Air Cooled

1.5 PROPELLERS

(a) Number of Propellers	1
(b) Propeller Manufacturer	McCaughey
(c) Model	IC160/EGM7653
(d) Number of Blades	2
(e) Propeller Diameter (inches)	
(1) Maximum	76
(2) Minimum	74.5
(f) Propeller Type	Fixed Pitch

1.7 FUEL

AVGAS ONLY

(a) Fuel Capacity (U.S. gal) (total)	50
(b) Usable Fuel (U.S. gal) (total)	48
(c) Fuel Grade, Aviation	
(1) Minimum Octane	80/87 Red
(2) Specified Octane	80/87 Red
(3) Alternate Fuel	Refer to Fuel Requirements, Section 8 - Handling, Servicing and Maintenance - paragraph 8.21, item (b).

1.9 OIL

(a) Oil Capacity (U.S. quarts)	8
(b) Oil Specification	Refer to latest issue of Lycoming Service Instruction 1014.
(c) Oil Viscosity per Average Ambient Temp. for Starting	
	SINGLE
(1) Above 60°F	S.A.E. 50
(2) 30°F to 90°F	S.A.E. 40
(3) 0°F to 70°F	S.A.E. 30
(4) Below 10°F	S.A.E. 20

1.11 MAXIMUM WEIGHTS

	NORMAL	UTILITY
(a) Maximum Takeoff Weight (lbs)	2325	1950
(b) Maximum Landing Weight (lbs)	2325	1950
(c) Maximum Weights in Baggage Compartment	200	0

1.13 STANDARD AIRPLANE WEIGHTS*

(a) Standard Empty Weight (lbs): Weight of a standard airplane including unusable fuel, full operating fluids and full oil.	1336
(b) Maximum Useful Load (lbs); The difference between the Maximum Takeoff Weight and the Standard Empty Weight.	989

1.15 BAGGAGE SPACE

(a) Compartment Volume (cubic feet)	24
(b) Entry Width (inches)	22
(c) Entry Height (inches)	20

1.17 SPECIFIC LOADINGS

(a) Wing Loading (lbs per sq ft)	13.7
(b) Power Loading (lbs per hp)	15.5

*These values are approximate and vary from one aircraft to another. Refer to Figure 6-5 for the Standard Empty Weight value and the Useful Load value to be used for C.G. calculations for the aircraft specified.

1.19 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY

The following definitions are of symbols, abbreviations and terminology used throughout the handbook and those which may be of added operational significance to the pilot.

(a) General Airspeed Terminology and Symbols

CAS	Calibrated Airspeed means the indicated speed of an aircraft, corrected for position and instrument error. Calibrated airspeed is equal to true airspeed in standard atmosphere at sea level.
KCAS	Calibrated Airspeed expressed in "Knots."
GS	Ground Speed is the speed of an airplane relative to the ground.
IAS	Indicated Airspeed is the speed of an aircraft as shown on the airspeed indicator when corrected for instrument error. IAS values published in this handbook assume zero instrument error.
KIAS	Indicated Airspeed expressed in "Knots."
M	Mach Number is the ratio of true airspeed to the speed of sound.
TAS	True Airspeed is the airspeed of an airplane relative to undisturbed air which is the CAS corrected for altitude, temperature and compressability.
V_A	Maneuvering Speed is the maximum speed at which application of full available aerodynamic control will not overstress the airplane.
V_{FE}	Maximum Flap Extended Speed is the highest speed permissible with wing flaps in a prescribed extended position.
V_{NE}/M_{NE}	Never Exceed Speed or Mach Number is the speed limit that may not be exceeded at any time.
V_{NO}	Maximum Structural Cruising Speed is the speed that should not be exceeded except in smooth air and then only with caution.
V_S	Stalling Speed or the minimum steady flight speed at which the airplane is controllable.
V_{SO}	Stalling Speed or the minimum steady flight speed at which the airplane is controllable in the landing configuration.
V_X	Best Angle-of-Climb Speed is the airspeed which delivers the greatest gain of altitude in the shortest possible horizontal distance.
V_Y	Best Rate-of-Climb Speed is the airspeed which delivers the greatest gain in altitude in the shortest possible time.

(b) Meteorological Terminology

ISA

International Standard Atmosphere in which:

The air is a dry perfect gas;

The temperature at sea level is 15° Celcius (59° Fahrenheit);

The pressure at sea level is 29.92 inches Hg. (1013.2 mb);

The temperature gradient from sea level to the altitude at which the temperature is -56.5° C (-69.7° F) is -0.00198° C (-0.003564° F) per foot and zero above that altitude.

OAT

Outside Air Temperature is the free air static temperature, obtained either from inflight temperature indications or ground meteorological sources, adjusted for instrument error and compressibility effects.

**Indicated Pressure
Altitude**

The number actually read from an altimeter when the barometric subscale has been set to 29.92 inches of mercury (1013.2 millibars).

Pressure Altitude

Altitude measured from standard sea-level pressure (29.92 in. Hg) by a pressure or barometric altimeter. It is the indicated pressure altitude corrected for position and instrument error. In this handbook, altimeter instrument errors are assumed to be zero.

Station Pressure

Actual atmospheric pressure at field elevation.

Wind

The wind velocities recorded as variables on the charts of this handbook are to be understood as the headwind or tailwind components of the reported winds.

(c) Power Terminology

Takeoff Power	Maximum power permissible for takeoff.
Maximum Continuous Power	Maximum power permissible continuously during flight.
Maximum Climb Power	Maximum power permissible during climb.
Maximum Cruise Power	Maximum power permissible during cruise.

(d) Engine Instruments

EGT Gauge	Exhaust Gas Temperature Gauge
-----------	-------------------------------

(e) Airplane Performance and Flight Planning Terminology

Climb Gradient	The demonstrated ratio of the change in height during a portion of a climb, to the horizontal distance traversed in the same time interval.
Demonstrated Crosswind Velocity	The demonstrated crosswind velocity is the velocity of the crosswind component for which adequate control of the airplane during takeoff and landing was actually demonstrated during certification tests.
Accelerate-Stop Distance	The distance required to accelerate an airplane to a specified speed and, assuming failure of an engine at the instant that speed is attained, to bring the airplane to a stop.
Route Segment	A part of a route. Each end of that part is identified by: (1) a geographical location; or (2) a point at which a definite radio fix can be established.

(f) Weight and Balance Terminology

Reference Datum	An imaginary vertical plane from which all horizontal distances are measured for balance purposes.
Station	A location along the airplane fuselage usually given in terms of distance from the reference datum.
Arm	The horizontal distance from the reference datum to the center of gravity (C.G.) of an item.
Moment	The product of the weight of an item multiplied by its arm. (Moment divided by a constant is used to simplify balance calculations by reducing the number of digits.)
Center of Gravity (C.G.)	The point at which an airplane would balance if suspended. Its distance from the reference datum is found by dividing the total moment by the total weight of the airplane.
C.G. Arm	The arm obtained by adding the airplane's individual moments and dividing the sum by the total weight.
C.G. Limits	The extreme center of gravity locations within which the airplane must be operated at a given weight.
Usable Fuel	Fuel available for flight planning.
Unusable Fuel	Fuel remaining after a runout test has been completed in accordance with governmental regulations.
Standard Empty Weight	Weight of a standard airplane including unusable fuel, full operating fluids and full oil.
Basic Empty Weight	Standard empty weight plus optional equipment.
Payload	Weight of occupants, cargo and baggage.
Useful Load	Difference between takeoff weight, or ramp weight if applicable, and basic empty weight.
Maximum Ramp Weight	Maximum weight approved for ground maneuver. (It includes weight of start, taxi and run up fuel.)
Maximum Takeoff Weight	Maximum weight approved for the start of the takeoff run.
Maximum Landing Weight	Maximum weight approved for the landing touchdown.
Maximum Zero Fuel Weight	Maximum weight exclusive of usable fuel.

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

1.21 CONVERSION FACTORS

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
atmospheres	76.00 29.92 14.696 21,116 1.033	cm Hg at 0°C in. Hg at 0°C lb/sq in. lb/sq ft kg/sq cm	feet	3.048×10^{-1} 3.333×10^{-1} 1.894×10^{-4} 1.646×10^{-4}	meters yards miles nautical miles
centimeters	0.3937 3.281×10^{-2}	in. ft	ft/min	1.136×10^{-2} 1.829×10^{-2} 5.080×10^{-1}	mph km/hr cm/sec
cm Hg	1.934×10^{-1} 27.85 135.95	lb/sq in. lb/sq ft kg/sq m	ft/sec	.6818 1.097 30.48 .5925	mph km/hr cm/sec knots
cm/second	3.281×10^{-2} 2.237×10^{-2}	ft/sec mph	ft/lb	1.383×10^{-1}	m-kg
cu centimeters	10^{-3} 6.102×10^{-2} 2.642×10^{-4}	liters cu in. U.S. gal	ft-lb/min	3.030×10^{-5}	hp
cu ft	2.832×10^{-4} 1,728 3.704×10^{-2} 7.481 28.32	cu cm cu in. cu yards U.S. gal liters	ft-lb/sec	1.818×10^{-3}	hp
cu ft/min	4.719×10^{-1} 2.832×10^{-2}	liters/sec cu m/min	fluid oz	8 29.6	dram cu cm
cu in.	16.39 1.639×10^{-2} 4.329×10^{-3} 1.732×10^{-2}	cu cm liters U.S. gal quarts	gal, Imperial	277.4 1.201 4.546	cu in. U.S. gal liters
cu meters	61,023 1.308 35.31 264.2	cu in. cu yards cu ft U.S. gal	gal, U.S. dry	268.8 1.556×10^{-1} 1.164 4.405	cu in. cu ft U.S. gal liquid liters
cu yards	27.0 7.646×10^{-1} 2.022×10^2	cu ft cu meters U.S. gal	gal, U.S. liquid	231.0 1.337×10^{-1} 3.785 8.327×10^{-1} 1.280×10^2	cu in. cu ft liters Imperial gal fluid oz
deg (arc)	1.745×10^{-2}	radians	grams/cm	0.1 6.721×10^{-2} 5.601×10^{-3}	kg/m lb/ft lb/in.
			grams/cu cm	1,000 62.43	kg/cu m lb/cu ft

**SECTION 1
GENERAL**

**PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR**

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>	<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
horsepower	33,000	ft-lb/min	liters	10^3	cu cm
	550	ft-lb/sec		61.03	cu in.
	76.04	m-kg/sec		3.532×10^{-2}	cu ft
	1.014	metric hp		2.642×10^{-1}	U.S. gal
				2.200×10^{-1}	Imperial gal
horsepower, metric	75.0	m-kg/sec		1.057	quarts
	9.863×10^{-1}	hp	meters	39.37	in.
inches	2.540	cm		3.281	ft
	83.33×10^{-3}	ft		1.094	yards
				6.214×10^{-4}	miles
in. Hg at 0°C	3.342×10^{-2}	atmospheres	meter-kilogram	7.233	ft-lb
	4.912×10^{-1}	lb/sq in.			
	70.73	lb/sq ft	meter/sec	3.281	ft/sec
	3.453×10^2	kg/sq m		2.237	miles/hr
kilograms	2.205	lb		3.600	km/hr
	35.27	oz	microns	3.937×10^{-5}	in.
	10^3	grams	miles	5280	ft
kg-calories	3087	ft-lb		1.609	km
	4.269×10^2	m-kg		8.690×10^{-1}	nautical miles
kg/cu m	62.43×10^{-3}	lb/cu ft	mph	1.467	ft/sec
	10^{-3}	grams/cu m		4.470×10^{-1}	m/sec
kg/sq cm	14.22	lb/cu ft		1.609	km/hr
	2.048×10^3	lb/sq ft		8.690×10^{-1}	knots
	28.96	in. Hg at 0°C	miles/hr sq	2.151	ft/sec sq
kilometers	3.281×10^3	ft	milibars	2.953×10^{-2}	in. Hg at 0°C
	6.214×10^{-1}	miles	nautical miles	6076.1	ft
	5.400×10^{-1}	nautical miles		1.151	miles
	10^5	centimeters		1852	m
km/hr	9.113×10^{-1}	ft/sec	ounces, fluid	29.57	cu cm
	5.396×10^{-1}	knots		1.805	cu in.
	6.214×10^{-1}	mph	lb/cu ft	16.02	kg/cu m
	2.778×10^{-1}	m/sec	lb/cu in.	1728	lb/cu ft
knots	1.0	nautical mph		27.68	grams/cu cm
	1.688	ft/sec			
	1.151	mph			
	1.853	km/hr			
	5.148×10^{-1}	m/sec			

<u>MULTIPLY</u>	<u>BY</u>	<u>TO OBTAIN</u>
lb/sq in.	2.036 6.805×10^{-2} 7.031×10^2	in. Hg at 0°C atmospheres kg/sq m
radians	57.30	deg (arc)
radians/sec	57.30 15.92×10^{-2} 9.549	deg/sec rev/sec rev/min
revolutions	6.283	radians
rev/min	1.047×10^{-1}	radians/sec
rod	16.5 5.5	ft yd
slug	32.174	lb
sq cm	1.550×10^{-1} 1.076×10^{-3}	sq in. sq ft
sq ft	929.0 144.0 1.111×10^{-1} 2.296×10^{-5}	sq cm sq in. sq yards acres
sq in.	6.452	sq cm
sq kilometers	3.861×10^{-1}	sq miles
sq meters	10.76 1.196	sq ft sq yards
sq miles	2.590 640	sq km acres
sq rods	30.25	sq yd
sq yards	8.361×10^{-1} 9	sq m sq ft
yards	9.144×10^{-1} 3.0 36.0	meters ft in.

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 2

LIMITATIONS

Paragraph No.		Page No.
2.1	General	2-1
2.3	Airspeed Limitations	2-1
2.5	Airspeed Indicator Markings	2-2
2.7	Power Plant Limitations	2-2
2.9	Power Plant Instrument Markings	2-3
2.11	Weight Limits	2-3
2.13	Center of Gravity Limits	2-4
2.15	Maneuver Limits	2-4
2.17	Flight Load Factors	2-4
2.19	Types of Operations	2-5
2.21	Fuel Limitations	2-5
2.23	Placards	2-7

SECTION 2 LIMITATIONS

2.1 GENERAL

This section provides the "FAA Approved" operating limitations, instrument markings, color coding and basic placards necessary for the operation of the airplane and its systems. |

This airplane must be operated as a normal or utility category airplane in compliance with the operating limitations stated in the form of placards and markings and those given in this section and handbook.

Limitations associated with those optional systems and equipment which require handbook supplements can be found in Section 9 (Supplements).

2.3 AIRSPEED LIMITATIONS

SPEED	KIAS	KCAS
Never Exceed Speed (V_{NE}) - Do not exceed this speed in any operation.	160	153
Maximum Structural Cruising Speed (V_{NO}) - Do not exceed this speed except in smooth air and then only with caution.	126	122
Design Maneuvering Speed (V_A) - Do not make full or abrupt control movements above this speed.		
At 2325 LBS. G.W.	111	108
At 1531 LBS. G.W.	88	89

CAUTION

Maneuvering speed decreases at lighter weight as the effects of aerodynamic forces become more pronounced. Linear interpolation may be used for intermediate gross weights. Maneuvering speed should not be exceeded while operating in rough air.

Maximum Flaps Extended Speed (V_{FE}) - Do not exceed this speed with the flaps extended.	103	100
---	-----	-----

**SECTION 2
LIMITATIONS**

**PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR**

2.5 AIRSPEED INDICATOR MARKINGS

MARKING	IAS
Red Radial Line (Never Exceed)	160 KTS
Yellow Arc (Caution Range - Smooth Air Only)	126 KTS to 160 KTS
Green Arc (Normal Operating Range)	50 KTS to 126 KTS
White Arc (Flap Down)	44 KTS to 103 KTS

2.7 POWER PLANT LIMITATIONS

(a) Number of Engines	1
(b) Engine Manufacturer	Lycoming
(c) Engine Model No.	O-320-E3D
(d) Engine Operating Limits	
(1) Maximum Horsepower	150
(2) Maximum Rotation Speed (RPM)	2700
(3) Maximum Oil Temperature	245° F
(e) Oil Pressure	
Minimum (red line)	25 PSI
Maximum (red line)	90 PSI
(f) Fuel Pressure	
Minimum (red line)	5 PSI
Maximum (red line)	8 PSI
(g) Fuel Grade (AVGAS ONLY) (minimum octane)	80/87 Red
(h) Number of Propellers	1
(i) Propeller Manufacturer	McCauley
(j) Propeller Model	1C160/EGM7653
(k) Propeller Diameter	
Minimum	74 IN.
Maximum	76 IN.
(l) Propeller Tolerance (static RPM at maximum permissible throttle setting)	
Not above	2400 RPM
Not below	2300 RPM
	2375 RPM
	2275 RPM

No additional tolerance permitted.

2.9 POWER PLANT INSTRUMENT MARKINGS

(a) Tachometer	
Green Arc (Normal Operating Range)	500 to 2700 RPM
Red Line (Maximum Continuous Power)	2700 RPM
(b) Oil Temperature	
Green Arc (Normal Operating Range)	75° to 245°F
Red Line (Maximum)	245°F
(c) Oil Pressure	
Green Arc (Normal Operating Range)	60 PSI to 90 PSI
Yellow Arc (Caution Range) (Idle)	25 PSI to 60 PSI
Red Line (Minimum)	25 PSI
Red Line (Maximum)	90 PSI
(d) Fuel Pressure	
Green Arc (Normal Operating Range)	.5 PSI to 8 PSI
Red Line (Minimum)	.5 PSI
Red Line (Maximum)	8 PSI

2.11 WEIGHT LIMITS

	NORMAL	UTILITY
(a) Maximum Weight	2325 LBS	1950 LBS
(b) Maximum Baggage	200 LBS	0 LBS

NOTE

Refer to Section 5 (Performance) for maximum weight as limited by performance.

2.13 CENTER OF GRAVITY LIMITS

(a) Normal Category

Weight Pounds	Forward Limit Inches Aft of Datum	Rearward Limit Inches Aft of Datum
2325	87.0	93.0
1950 (and less)	83.0	93.0

(b) Utility Category

Weight Pounds	Forward Limit Inches Aft of Datum	Rearward Limit Inches Aft of Datum
1950 (and less)	83.0	86.5

NOTES

Straight line variation between points given.

The datum used is 78.4 inches ahead of the wing leading edge at the inboard intersection of the straight and tapered section.

It is the responsibility of the airplane owner and the pilot to insure that the airplane is properly loaded. See Section 6 (Weight and Balance) for proper loading instructions.

2.15 MANEUVER LIMITS

- (a) Normal Category - All acrobatic maneuvers including spins prohibited.
- (b) Utility Category - Approved maneuvers for bank angles exceeding 60°:

	Entry Speed
Steep Turns	111 KIAS
Lazy Eights	111 KIAS
Chandelles	111 KIAS

2.17 FLIGHT LOAD FACTORS

	NORMAL	UTILITY
(a) Positive Load Factor (Maximum)	3.8 G	4.4 G
(b) Negative Load Factor (Maximum)	No inverted maneuvers approved	

2.19 TYPES OF OPERATION

The airplane is approved for the following operations when equipped in accordance with FAR 91 or FAR 135.

- (a) Day V.F.R.
- (b) Night V.F.R.
- (c) Day I.F.R.
- (d) Night I.F.R.
- (e) Non Icing

2.21 FUEL LIMITATIONS

- | | |
|--|-------------|
| (a) Total Capacity | 50 U.S. GAL |
| (b) Unusable Fuel | 2 U.S. GAL |
| The unusable fuel for this airplane has been determined as 1.0 gallon in each wing in critical flight attitudes. | |
| (c) Usable Fuel | 48 U.S. GAL |
| The usable fuel in this airplane has been determined as 24.0 gallons in each wing. | |

THIS PAGE INTENTIONALLY LEFT BLANK

2.23 PLACARDS

In full view of the pilot:

"THIS AIRPLANE MUST BE OPERATED AS A NORMAL OR UTILITY CATEGORY AIRPLANE IN COMPLIANCE WITH THE OPERATING LIMITATIONS STATED IN THE FORM OF PLACARDS, MARKINGS AND MANUALS.

ALL MARKINGS AND PLACARDS ON THIS AIRPLANE APPLY TO ITS OPERATION AS A UTILITY CATEGORY AIRPLANE. FOR NORMAL AND UTILITY CATEGORY OPERATION, REFER TO THE PILOT'S OPERATING HANDBOOK.

NO ACROBATIC MANEUVERS ARE APPROVED FOR NORMAL CATEGORY OPERATIONS. SPINS ARE PROHIBITED FOR BOTH NORMAL AND UTILITY CATEGORY."

In full view of the pilot, the following takeoff and landing check lists will be installed:

TAKEOFF CHECK LIST

Fuel on proper tank
Electric fuel pump on
Engine gauges checked
Flaps - set
Carb heat off

Mixture set
Seat backs erect

Fasten belts/harness
Trim tab - set
Controls - free
Door - latched

LANDING CHECK LIST

Fuel on proper tank
Mixture rich
Electric fuel pump on

Seat backs erect

Flaps - set (103 KIAS max.)
Fasten belts/harness

Adjacent to upper door latch:

"ENGAGE LATCH BEFORE FLIGHT."

On inside of the baggage compartment door:

"BAGGAGE MAXIMUM 200 LBS"

"UTILITY CATEGORY OPERATION - NO BAGGAGE OR AFT
PASSENGERS ALLOWED. NORMAL CATEGORY OPERATION
- SEE PILOT'S OPERATING HANDBOOK WEIGHT AND
BALANCE SECTION FOR BAGGAGE AND AFT PASSENGER
LIMITATIONS."

In full view of the pilot:

"MANEUVERING SPEED 111 KIAS AT 2325 LBS. (SEE
P.O.H.)"

"UTILITY CATEGORY OPERATION - NO AFT PASSENGERS
ALLOWED."

"DEMONSTRATED CROSS WIND COMPONENT - 17 KTS."

On the instrument panel in full view of the pilot when the oil cooler winterization kit is installed:

"OIL COOLER WINTERIZATION PLATE TO BE REMOVED
WHEN AMBIENT TEMPERATURE EXCEEDS 50°F."

In full view of the pilot:

"UTILITY CATEGORY OPERATION ONLY."

- (1) NO AFT PASSENGERS ALLOWED.
- (2) ACROBATIC MANEUVERS ARE LIMITED TO THE FOLLOWING:

	ENTRY SPEED
SPINS PROHIBITED	
STEEP TURNS	111 KIAS
LAZY EIGHTS	111 KIAS
CHANDELLES	111 KIAS

On the instrument panel in full view of the pilot:

"WARNING - TURN OFF STROBE LIGHTS WHEN TAXIING
IN VICINITY OF OTHER AIRCRAFT, OR DURING FLIGHT
THROUGH CLOUD, FOG OR HAZE."

TABLE OF CONTENTS

SECTION 3

EMERGENCY PROCEDURES

Paragraph No.		Page No.
3.1	General	3-1
3.3	Emergency Procedures Checklist	3-3
	Engine Fire During Start	3-3
	Engine Power Loss During Takeoff	3-3
	Engine Power Loss In Flight	3-3
	Power Off Landing	3-3
	Fire In Flight	3-3
	Loss of Oil Pressure	3-3
	Loss of Fuel Pressure	3-4
	High Oil Temperature	3-4
	Alternator Failure	3-4
	Spin Recovery	3-4
	Open Door	3-4
	Engine Roughness	3-4
3.5	Amplified Emergency Procedures (General)	3-7
3.7	Engine Fire During Start	3-7
3.9	Engine Power Loss During Takeoff	3-7
3.11	Engine Power Loss In Flight	3-8
3.13	Power Off Landing	3-8
3.15	Fire In Flight	3-9
3.17	Loss of Oil Pressure	3-9
3.19	Loss of Fuel Pressure	3-10
3.21	High Oil Temperature	3-10
3.23	Alternator Failure	3-10
3.25	Spin Recovery	3-10
3.27	Open Door	3-11
3.29	Engine Roughness	3-11

**SECTION 3
EMERGENCY PROCEDURES**

3.1 GENERAL

The recommended procedures for coping with various types of emergencies and critical situations are provided in this section. All required (FAA regulations) emergency procedures and those necessary for the operation of the airplane as determined by the operating and design features of the airplane are presented.

Emergency procedures associated with those optional systems and equipment which require handbook supplements are provided in Section 9 (Supplements).

The first portion of this section consists of an abbreviated emergency checklist which supplies an action sequence for critical situations with little emphasis on the operation of systems.

The remainder of the section is devoted to amplified emergency procedures containing additional information to provide the pilot with a more complete understanding of the procedures.

These procedures are suggested as a course of action for coping with the particular condition described, but are not a substitute for sound judgment and common sense. Pilots should familiarize themselves with the procedures given in this section and be prepared to take appropriate action should an emergency arise.

Most basic emergency procedures, such as power off landings, are a normal part of pilot training. Although these emergencies are discussed here, this information is not intended to replace such training, but only to provide a source of reference and review, and to provide information on procedures which are not the same for all aircraft. It is suggested that the pilot review standard emergency procedures periodically to remain proficient in them.

THIS PAGE INTENTIONALLY LEFT BLANK

3.3 EMERGENCY PROCEDURES CHECK LIST

ENGINE FIRE DURING START

Starter crank engine
Mixture idle cut-off
Throttle open
Electric fuel pump OFF
Fuel selector OFF
Abandon if fire continues

ENGINE POWER LOSS DURING TAKEOFF

If sufficient runway remains for a normal landing,
land straight ahead.

If insufficient runway remains:

Maintain safe airspeed
Make only shallow turn to avoid obstructions
Flaps as situation requires

If sufficient altitude has been gained to attempt a
restart:

Maintain safe airspeed
Fuel selector switch to tank
containing fuel

Electric fuel pump check ON
Mixture check RICH
Carburetor heat ON

If power is not regained, proceed with power off
landing.

ENGINE POWER LOSS IN FLIGHT

Fuel selector switch to tank
containing fuel
Electric fuel pump ON
Mixture RICH
Carburetor heat ON
Engine gauges check for indication
of cause of power loss

Primer check locked
If no fuel pressure is indicated, check tank selector
position to be sure it is on a tank containing fuel.

When power is restored:

Carburetor heat OFF
Electric fuel pump OFF

If power is not restored prepare for power off
landing.

Trim for 73 KIAS

POWER OFF LANDING

Locate suitable field.

Establish spiral pattern.

1000 ft. above field at downwind position for
normal landing approach.

When field can easily be reached slow to 63 KIAS
for shortest landing.

Touchdowns should normally be made at lowest
possible airspeed with full flaps.

When committed to landing:

Ignition OFF
Master switch OFF
Fuel selector OFF
Mixture idle cut-off
Seat belt and harness tight

FIRE IN FLIGHT

Source of fire check

Electrical fire (smoke in cabin):

Master switch OFF
Vents open
Cabin heat OFF
Land as soon as practicable.

Engine fire:

Fuel selector OFF
Throttle CLOSED
Mixture idle cut-off
Electric fuel pump check OFF
Heater OFF
Defroster OFF
Proceed with POWER OFF LANDING procedure.

LOSS OF OIL PRESSURE

Land as soon as possible and investigate cause.
Prepare for power off landing.

LOSS OF FUEL PRESSURE

Electric fuel pump ON
Fuel selector check on full tank

HIGH OIL TEMPERATURE

Land at nearest airport and investigate the problem.
Prepare for power off landing.

ALTERNATOR FAILURE

Verify failure
Reduce electrical load as much as possible.
Alternator circuit breakers check
Alt switch OFF (for 1 second),
then on

If no output:
Alt switch OFF

Reduce electrical load and land as soon as practical.

SPIN RECOVERY

Throttle idle
Ailerons neutral
Rudder full opposite to
direction of rotation
Control wheel full forward
Rudder neutral (when
rotation stops)
Control wheel as required to smoothly
regain level flight altitude

OPEN DOOR

If both upper and lower latches are open, the door will trail slightly open and airspeeds will be reduced slightly.

To close the door in flight:

Slow airplane to 89 KIAS

Cabin vents close
Storm window open

If upper latch is open latch

If lower latch is open open top latch, push
door further open and
close rapidly. Latch top
latch.

A slip in direction of open door will assist latching.

ENGINE ROUGHNESS

Carburetor heat ON

If roughness continues after one min:

Carburetor heat OFF
Mixture adjust for max.
smoothness

Electric fuel pump ON
Fuel selector switch tanks
Engine gauges check
Magneto switch "L" then "R"
then "BOTH"

If operation is satisfactory on either one, continue on that magneto at reduced power and full "RICH" mixture to first airport.

Prepare for power off landing.

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

3.5 AMPLIFIED EMERGENCY PROCEDURES (GENERAL)

The following paragraphs are presented to supply additional information for the purpose of providing the pilot with a more complete understanding of the recommended course of action and probable cause of an emergency situation.

3.7 ENGINE FIRE DURING START

Engine fires during start are usually the result of overpriming. The first attempt to extinguish the fire is to try to start the engine and draw the excess fuel back into the induction system.

If a fire is present before the engine has started, move the mixture control to idle cut-off, open the throttle and crank the engine. This is an attempt to draw the fire back into the engine.

If the engine has started, continue operating to try to pull the fire into the engine.

In either case (above), if fire continues more than a few seconds, the fire should be extinguished by the best available external means.

The fuel selector valves should be "OFF" and the mixture at idle cut-off if an external fire extinguishing method is to be used.

3.9 ENGINE POWER LOSS DURING TAKEOFF

The proper action to be taken if loss of power occurs during takeoff will depend on the circumstances of the particular situation.

If sufficient runway remains to complete a normal landing, land straight ahead.

If insufficient runway remains, maintain a safe airspeed and make only a shallow turn if necessary to avoid obstructions. Use of flaps depends on the circumstances. Normally, flaps should be fully extended for touchdown.

If sufficient altitude has been gained to attempt a restart, maintain a safe airspeed and switch the fuel selector to another tank containing fuel. Check the electric fuel pump to insure that it is "ON" and that the mixture is "RICH." The carburetor heat should be "ON."

If engine failure was caused by fuel exhaustion, power will not be regained after switching fuel tanks until the empty fuel lines are filled. This may require up to ten seconds.

If power is not regained, proceed with the Power Off Landing procedure (refer to the emergency check list and paragraph 3.13).

3.11 ENGINE POWER LOSS IN FLIGHT

Complete engine power loss is usually caused by fuel flow interruption and power will be restored shortly after fuel flow is restored. If power loss occurs at a low altitude, the first step is to prepare for an emergency landing (refer to paragraph 3.13). An airspeed of at least 73 KIAS should be maintained.

If altitude permits, switch the fuel selector to another tank containing fuel and turn the electric fuel pump "ON." Move the mixture control to "RICH" and the carburetor heat to "ON." Check the engine gauges for an indication of the cause of the power loss. Check to insure the primer is locked. If no fuel pressure is indicated, check the tank selector position to be sure it is on a tank containing fuel.

When power is restored move the carburetor heat to the "OFF" position and turn "OFF" the electric fuel pump.

If the preceding steps do not restore power, prepare for an emergency landing.

If time permits, turn the ignition switch to "L" then to "R" then back to "BOTH." Move the throttle and mixture control levers to different settings. This may restore power if the problem is too rich or too lean a mixture or if there is a partial fuel system restriction. Try other fuel tanks. Water in the fuel could take some time to be used up, and allowing the engine to windmill may restore power. If power loss is due to water, fuel pressure indications will be normal.

If engine failure was caused by fuel exhaustion power will not be restored after switching fuel tanks until the empty fuel lines are filled. This may require up to ten seconds.

If power is not regained, proceed with the Power Off Landing procedure (refer to the emergency check list and paragraph 3.13).

3.13 POWER OFF LANDING

If loss of power occurs at altitude, trim the aircraft for best gliding angle (73 KIAS) and look for a suitable field. If measures taken to restore power are not effective, and if time permits, check your charts for airports in the immediate vicinity; it may be possible to land at one if you have sufficient altitude. If possible, notify the FAA by radio of your difficulty and intentions. If another pilot or passenger is aboard, let him help.

When you have located a suitable field, establish a spiral pattern around this field. Try to be at 1000 feet above the field at the downwind position, to make a normal landing approach. When the field can easily be reached, slow to 63 KIAS for the shortest landing. Excess altitude may be lost by widening your pattern, using flaps or slipping, or a combination of these.

Touchdown should normally be made at the lowest possible airspeed.

When committed to a landing shut "OFF" the master and ignition switches. Flaps may be used as desired. Turn the fuel selector valve to "OFF" and move the mixture to idle cut-off. The seat belts and shoulder harness should be tightened. Touchdown should be normally made at the lowest possible airspeed.

3.15 FIRE IN FLIGHT

The presence of fire is noted through smoke, smell and heat in the cabin. It is essential that the source of the fire be promptly identified through instrument readings, character of the smoke, or other indications since the action to be taken differs somewhat in each case.

Check for the source of the fire first.

If an electrical fire is indicated (smoke in the cabin), the master switch should be turned "OFF." The cabin vents should be opened and the cabin heat turned "OFF." A landing should be made as soon as possible.

If an engine fire is present, switch the fuel selector to "OFF" and close the throttle. The mixture should be at idle cut-off. Turn the electric fuel pump "OFF." In all cases, the heater and defroster should be "OFF." If radio communication is not required, select master switch "OFF." Proceed with power off landing procedure.

NOTE

The possibility of an engine fire in flight is extremely remote. The procedure given is general and pilot judgment should be the determining factor for action in such an emergency.

3.17 LOSS OF OIL PRESSURE

Loss of oil pressure may be either partial or complete. A partial loss of oil pressure usually indicates a malfunction in the oil pressure regulating system, and a landing should be made as soon as possible to investigate the cause and prevent engine damage.

A complete loss of oil pressure indication may signify oil exhaustion or may be the result of a faulty gauge. In either case, proceed toward the nearest airport, and be prepared for a forced landing. If the problem is not a pressure gauge malfunction, the engine may stop suddenly. Maintain altitude until such time as a dead stick landing can be accomplished. Don't change power settings unnecessarily, as this may hasten complete power loss.

Depending on the circumstances, it may be advisable to make an off airport landing while power is still available, particularly if other indications of actual oil pressure loss, such as sudden increases in temperatures, or oil smoke, are apparent, and an airport is not close.

If engine stoppage occurs, proceed with Power Off Landing.

3.19 LOSS OF FUEL PRESSURE

If loss of fuel pressure occurs, turn "ON" the electric fuel pump and check that the fuel selector is on a full tank.

If the problem is not an empty tank, land as soon as practical and have the engine-driven fuel pump and fuel system checked.

3.21 HIGH OIL TEMPERATURE

An abnormally high oil temperature indication may be caused by a low oil level, an obstruction in the oil cooler, damaged or improper baffle seals, a defective gauge, or other causes. Land as soon as practical at an appropriate airport and have the cause investigated.

A steady, rapid rise in oil temperature is a sign of trouble. Land at the nearest airport and let a mechanic investigate the problem. Watch the oil pressure gauge for an accompanying loss of pressure.

3.23 ALTERNATOR FAILURE

Loss of alternator output is detected through zero reading on the ammeter and illumination of the ALT light in the annunciator panel. Before executing the following procedure, insure that the reading is zero and not merely low by actuating an electrically powered device, such as the landing light. If no increase in the ammeter reading is noted, alternator failure can be assumed.

The electrical load should be reduced as much as possible. Check the alternator circuit breakers for a popped circuit.

The next step is to attempt to reset the overvoltage relay. This is accomplished by moving the "ALT" switch to "OFF" for one second and then to "ON." If the trouble was caused by a momentary overvoltage condition (16.5 volts and up) this procedure should return the ammeter to a normal reading.

If the ammeter continues to indicate "O" output, or if the alternator will not remain reset, turn off the "ALT" switch, maintain minimum electrical load and land as soon as practical. All electrical load is being supplied by the battery.

3.25 SPIN RECOVERY

Intentional spins are prohibited in this airplane. If a spin is inadvertently entered, immediately move the throttle to idle and the ailerons to neutral.

Full rudder should then be applied opposite to the direction of rotation followed by control wheel full forward. When the rotation stops, neutralize the rudder and ease back on the control wheel as required to smoothly regain a level flight attitude.

3.27 OPEN DOOR

The cabin door on the Cherokee is double latched, so the chances of its springing open in flight at both the top and side are remote. However, should you forget the upper latch, or not fully engage the side latch, the door may spring partially open. This will usually happen at takeoff or soon afterward. A partially open door will not affect normal flight characteristics, and a normal landing can be made with the door open.

If both upper and side latches are open, the door will trail slightly open, and airspeed will be reduced slightly.

To close the door in flight, slow the airplane to 89 KIAS, close the cabin vents and open the storm window. If the top latch is open, latch it. If the side latch is open, pull on the armrest while moving the latch handle to the latched position. If both latches are open, close the side latch then the top latch.

3.29 ENGINE ROUGHNESS

Engine roughness is usually due to carburetor icing which is indicated by a drop in RPM, and may be accompanied by a slight loss of airspeed or altitude. If too much ice is allowed to accumulate, restoration of full power may not be possible; therefore, prompt action is required.

Turn carburetor heat on (See Note). RPM will decrease slightly and roughness will increase. Wait for a decrease in engine roughness or an increase in RPM, indicating ice removal. If no change in approximately one minute, return the carburetor heat to "OFF."

If the engine is still rough, adjust the mixture for maximum smoothness. The engine will run rough if too rich or too lean. The electric fuel pump should be switched to "ON" and the fuel selector switched to the other tank to see if fuel contamination is the problem. Check the engine gauges for abnormal readings. If any gauge readings are abnormal, proceed accordingly. Move the magneto switch to "L" then to "R," then back to "BOTH." If operation is satisfactory on either magneto, proceed on that magneto at reduced power, with mixture full "RICH," to a landing at the first available airport.

If roughness persists, prepare for a precautionary landing at pilot's discretion.

NOTE

Partial carburetor heat may be worse than no heat at all, since it may melt part of the ice, which will refreeze in the intake system. When using carburetor heat, therefore, always use full heat, and when ice is removed return the control to the full cold position.

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 4

NORMAL PROCEDURES

Paragraph No.		Page No.
4.1	General	4-1
4.3	Airspeeds for Safe Operations	4-3
4.5	Normal Procedures Checklist.....	4-3
	Preflight Check	4-3
	Before Starting Engine	4-4
	Starting Engine When Cold	4-4
	Starting Engine When Hot	4-4
	Starting Engine When Flooded	4-4
	Starting Engine With External Power Source	4-4
	Warm-Up	4-4
	Taxiing	4-4
	Ground Check	4-4
	Before Takeoff.....	4-5
	Takeoff	4-5
	Climb	4-5
	Cruising	4-5
	Approach and Landing	4-5
	Stopping Engine	4-6
	Mooring	4-6
4.7	Amplified Normal Procedures (General)	4-7
4.9	Preflight Check.....	4-7
4.11	Before Starting Engine	4-8
4.13	Starting Engine.....	4-9
4.15	Warm-Up	4-11
4.17	Taxiing.....	4-11
4.19	Ground Check	4-11
4.21	Before Takeoff	4-12
4.23	Takeoff	4-12
4.25	Climb	4-13
4.27	Cruising	4-13
4.29	Approach and Landing	4-14
4.31	Stopping Engine.....	4-14
4.33	Mooring.....	4-15
4.35	Stalls	4-15
4.37	Turbulent Air Operation.....	4-16
4.39	Weight and Balance.....	4-16

SECTION 4 NORMAL PROCEDURES

4.1 GENERAL

This section clearly describes the recommended procedures for the conduct of normal operations for the Cherokee Warrior. All of the required (FAA regulations) procedures and those necessary for the operation of the airplane as determined by the operating and design features of the airplane are presented.

Normal procedures associated with those optional systems and equipment which require handbook supplements are provided in Section 9 (Supplements).

These procedures are provided to present a source of reference and review and to supply information on procedures which are not the same for all aircraft. Pilots should familiarize themselves with the procedures given in this section in order to become proficient in the normal operations of the airplane.

The first portion of this section consists of a short form checklist which supplies an action sequence for normal operations with little emphasis on the operation of the systems.

The remainder of the section is devoted to amplified normal procedures which provide detailed information and explanations of the procedures and how to perform them. This portion of the section is not intended for use as an in-flight reference due to the lengthy explanations. The short form checklist should be used for this purpose.


4.3 AIRSPEEDS FOR SAFE OPERATIONS

The following airspeeds are those which are significant to the operation of the airplane. These figures are for standard airplanes flown at gross weight under standard conditions at sea level.

Performance for a specific airplane may vary from published figures depending upon the equipment installed, the condition of the engine, airplane and equipment, atmospheric conditions and piloting technique.

(a) Best Rate of Climb Speed	75 KIAS
(b) Best Angle of Climb Speed	63 KIAS
(c) Turbulent Air Operating Speed (See Subsection 2.3)	111 KIAS
(d) Maximum Flap Speed	103 KIAS
(e) Landing Final Approach Speed (Flaps 40°)	63 KIAS
(f) Maximum Demonstrated Crosswind Velocity	17 KTS

THIS PAGE INTENTIONALLY LEFT BLANK



WALK-AROUND

Figure 4-1

4.5 NORMAL PROCEDURES CHECKLIST

PREFLIGHT CHECK

Control wheel	release belts
Parking brake	set
Master switch	ON
Fuel quantity gauges	check
Master switch	OFF
Ignition	OFF
Exterior	check for damage
Control surfaces	check for interference - free of ice, snow, frost
Hinges	check for interference
Wings	free of ice, snow, frost
Stall warning	check
Navigation lights	check
Fuel tanks	check supply visually - secure caps
Fuel tank sumps	drain and check for water, sediment, and proper fuel
Fuel vents	open
Main gear struts	proper inflation (4.50 in.)
Tires	check
Brake blocks	check

Pitot head	remove cover - holes clear
Windshield	clean
Propeller and spinner.....	check
Fuel and oil	check for leaks
Oil	check level
Dipstick	properly seated
Cowling	secure
Inspection covers	secure
Nose wheel tire	check
Nose gear strut	proper inflation (3.25 in.)
Air inlets	clear
Alternator belt.....	check tension
Tow bar and control locks	stow
Baggage	stowed properly - secure
Baggage door.....	close and secure
Fuel strainer	drain and check for water, sediment, and proper fuel
Primary flight controls.....	proper operation
Cabin door.....	close and secure
Required papers	on board
Seat belts and harness	fastened - check inertia reel

SECTION 4

NORMAL PROCEDURES

**PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR**

BEFORE STARTING ENGINE

| Parking brake set
Carburetor heat full OFF
Fuel selector desired tank

STARTING ENGINE WHEN COLD

Throttle ¼" open
Master switch ON
Electric fuel pump ON
Mixture full RICH
Starter engage
Throttle adjust
Oil pressure check

If engine does not start within 10 sec. prime and repeat starting procedure.

STARTING ENGINE WHEN HOT

Throttle ½" open
Master switch ON
Electric fuel pump ON
Mixture full RICH
Starter engage
Throttle adjust
Oil pressure check

STARTING ENGINE WHEN FLOODED

Throttle open full
Master switch ON
Electric fuel pump OFF
Mixture idle cut-off
Starter..... engage
Mixture advance
Throttle retard
Oil pressure check

STARTING WITH EXTERNAL POWER SOURCE

Master switch OFF
All electrical equipment OFF
Terminals connect
External power plug insert in
fuselage

Proceed with normal start

Throttlelowest possible
RPM

External power plugdisconnect from fuselage

Master switch ON - check ammeter
Oil pressure check

WARM-UP

Throttle 800 to 1200 RPM

TAXIING

Chocks removed
Parking brake released
Taxi area clear
Throttle apply slowly
Brakes check
Steering check

GROUND CHECK

Parking brake	set
Throttle	2000 RPM
Magnetos	max. drop 175 RPM
	-max. diff. 50 RPM
Vacuum	5.0" Hg. +/- .1
Oil temp	check
Oil pressure	check
Annunciator panel	press-to-test
Carburetor heat	check
Engine is warm for takeoff when throttle can be opened without engine faltering.	
Electric fuel pump	OFF
Fuel pressure	check
Throttle	retard

STOPPING ENGINE

Flapsretract
Electric fuel pumpOFF
RadiosOFF
Throttlefull aft
Mixtureidle cut-off
MagnetosOFF
Master switchOFF

PARKING

Parking brakeset
Control wheelsecured with belts
Flapsfull up
Wheel chocksin place
Tie downssecure

4.7 AMPLIFIED NORMAL PROCEDURES (GENERAL)

The following paragraphs are provided to supply detailed information and explanations of the normal procedures necessary for the operation of the airplane.

4.9 PREFLIGHT CHECK

The airplane should be given a thorough preflight and walk-around check. The preflight should include a check of the airplane's operational status, computation of weight and C.G. limits, takeoff distance and in-flight performance. A weather briefing should be obtained for the intended flight path, and any other factors relating to a safe flight should be checked before takeoff.

CAUTION

The flap position should be noted before boarding the airplane. The flaps must be placed in the UP position before they will lock and support weight on the step.

Upon entering the cockpit, release the seat belts securing the control wheel and set the parking brake. Turn ON the master switch and check the fuel quantity gauges for sufficient fuel. After the fuel quantity check is made turn the master switch OFF and check that the ignition switch is OFF.

To begin the exterior walk-around, check for external damage and operational interference of the control surfaces or hinges. Ensure that the wings and control surfaces are free of snow, ice, frost or any other foreign materials.

An operational check of the stall warning system and navigation lights should now be made. Turn the master switch ON. Lift the detector while checking to determine if the horn is actuated and check that the navigation lights are illuminated. The master switch should be returned to the OFF position after the checks are complete.

A visual check of the fuel tank quantity should be performed. Remove the filler cap from each tank and visually check the supply. Be sure to secure the caps properly after the check is complete.

The fuel system sumps and strainer should be drained daily prior to the first flight and after refueling to check for water, sediment, and proper fuel. Each fuel tank is supplied with an individual quick drain located at the lower inboard rear corner of the tank. The fuel strainer is equipped with a quick drain located on the front lower corner of the firewall. Each of the fuel tank sumps should be drained first. Then the fuel strainer should be drained twice, once with the fuel selector valve on each tank. Each time fuel is drained, allow a sufficient amount to flow and be collected in a suitable container, so that it may be examined to ensure removal of water and sediments, and for proper fuel; then discard.

CAUTION

When draining any amount of fuel, care should be taken to ensure that no fire hazard exists before starting the engine.

Each quick drain should be checked after closing it to make sure it has closed completely and is not leaking.

Check all of the fuel tank vents to make sure they are open.

Next, complete a check of the landing gear. Check the main gear shock struts for proper inflation. There should be 4.50 inches of strut exposure under a normal static load. The nose gear should be checked for 3.25 inches of strut exposure. Check all tires for cuts and wear and ensure proper inflation. Make a visual check of the brake blocks for wear or damage.

Remove the cover from the pitot head on the underside of the left wing. Check the pitot head to make sure the holes are open and clear of obstructions.

Don't forget to clean and check the windshield.

The propeller and spinner should be checked for defects or nicks.

Lift the cowling and check for any obvious fuel or oil leaks. Check the oil level. Make sure that the dipstick has properly seated after checking. Secure the cowling and check the inspection covers.

Check the air inlets for foreign matter and the alternator belt for proper tension.

Stow the tow bar and check the baggage for proper storage and security. The baggage compartment doors should be closed and secure.

Upon entering the aircraft, ascertain that all primary flight controls operate properly. Close and secure the cabin door and check that all the required papers are in order and in the airplane.

Fasten the seat belts and shoulder harness and check the function of the inertia reel by pulling sharply on the strap. Fasten seat belts on empty seats.

4.11 BEFORE STARTING ENGINE

Before starting the engine the parking brake should be set ON and the carburetor heat lever moved to the full OFF position. The fuel selector should then be moved to the desired tank.

4.13 STARTING ENGINE

(a) Starting Engine When Cold

Open the throttle lever approximately 1/4 inch. Turn "ON" the master switch and the electric fuel pump.

Move the mixture control to full "RICH" and engage the starter by rotating the magneto switch clockwise and pressing in. When the engine fires, release the magneto switch, and move the throttle to the desired setting.

If the engine does not fire within five to ten seconds, disengage the starter, prime the engine and repeat the starting procedure.

(b) Starting Engine When Hot

Open the throttle approximately 1/2 inch. Turn "ON" the master switch and the electric fuel pump. Move the mixture control lever to full RICH and engage the starter by rotating the magneto switch clockwise and pressing in. When the engine fires, release the magneto switch and move the throttle to the desired setting.

(c) Starting Engine When Flooded

The throttle lever should be full "OPEN." Turn "ON" the master switch and turn "OFF" the electric fuel pump. Move the mixture control lever to idle cut-off and engage the starter by rotating the magneto switch clockwise and pressing in. When the engine fires, release the magneto switch, advance the mixture and retard the throttle.

(d) Starting Engine With External Power Source

An optional feature called the Piper External Power (PEP) allows the operator to use an external battery to crank the engine without having to gain access to the airplane's battery.

Connect the RED lead of the PEP kit jumper cable to the POSITIVE (+) terminal of an external 12-volt battery and the BLACK lead to the NEGATIVE (-) terminal. Insert the plug of the jumper cable to the socket located on the fuselage.

After the engine has started, disconnect the jumper cable from the airplane. With the master switch in the "ON" position check the alternator ammeter for an indication of output. DO NOT ATTEMPT FLIGHT IF THERE IS NO INDICATION OF ALTERNATOR OUTPUT.

When the engine is firing evenly, advance the throttle to 800 RPM. If oil pressure is not indicated within thirty seconds, stop the engine and determine the trouble. In cold weather it will take a few seconds longer to get an oil pressure indication. If the engine has failed to start, refer to the Lycoming Operating Handbook, Engine Troubles and Their Remedies.

Starter manufacturers recommend that cranking periods be limited to thirty seconds with a two minute rest between cranking periods. Longer cranking periods will shorten the life of the starter.

THIS PAGE INTENTIONALLY LEFT BLANK

4.15 WARM-UP

Warm-up the engine at 800 to 1200 RPM for not more than two minutes in warm weather and four minutes in cold. Avoid prolonged idling at low RPM, as this practice may result in fouled spark plugs.

Takeoff may be made as soon as the ground check is completed, provided that the throttle may be opened fully without backfiring or skipping, and without a reduction in engine oil pressure.

Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel or any loose material that may cause damage to the propeller blades.

4.17 TAXIING

Before attempting to taxi the airplane, ground personnel should be instructed and approved by a qualified person authorized by the owner. Ascertain that the wheel chocks have been removed and propeller back blast and taxi areas are clear. Release the parking brake.

Power should be applied slowly to start the taxi roll. Taxi a few feet forward and apply the brakes to determine the effectiveness. While taxiing, make slight turns to ascertain the effectiveness of the steering.

Observe wing clearances when taxiing near buildings or other stationary objects. If possible, station an observer outside the airplane.

Avoid holes and ruts when taxiing over uneven ground.

Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel or any loose material that may cause damage to the propeller blades.

4.19 GROUND CHECK

Set the parking brake. The magnetos should be checked at 2000 RPM. Drop off on either magneto should not exceed 175 RPM and the difference between the magnetos should not exceed 50 RPM. Operation on one magneto should not exceed 10 seconds.

Check the vacuum gauge; the indicator should read 5.0" +/- .1" Hg at 2000 RPM.

Check the annunciator panel lights with the press-to-test button.

Carburetor heat should also be checked prior to takeoff to be sure the control is operating properly and to clear any ice which may have formed during taxiing. Avoid prolonged ground operation with carburetor heat ON as the air is unfiltered.

The electric fuel pump should be turned OFF after starting or during warm-up to make sure that the engine driven pump is operating. Prior to takeoff the electric pump should be turned ON again to prevent loss of power during takeoff should the engine driven pump fail. Check both oil temperature and oil pressure. The temperature may be low for some time if the engine is being run for the first time of the day. The engine is warm enough for takeoff when the throttle can be opened without the engine faltering.

4.21 BEFORE TAKEOFF

All aspects of each particular takeoff should be considered prior to executing the takeoff procedure.

Turn ON the master switch and check and set all of the flight instruments as required. Check the fuel selector to make sure it is on the proper tank (fullest). Turn ON the electric fuel pump and check the engine gauges. The carburetor heat should be in the OFF position.

All seat backs should be erect and the seat belts and shoulder harness fastened. Fasten the seat belts snugly around the empty seats.

The mixture should be set.

NOTE

The mixture should be set FULL RICH except a minimum amount of leaning is permitted for smooth engine operation when taking off at high elevation.

Exercise and set the flaps and trim tab. Ensure proper flight control movement and response.

All doors should be properly secured and latched.

Release the parking brake.

4.23 TAKEOFF

The normal takeoff technique is conventional for the Cherokee Warrior. The tab should be set slightly aft of neutral, with the exact setting determined by the loading of the airplane. Allow the airplane to accelerate to 45 to 55 KIAS depending on the weight of the aircraft and ease back on the control wheel to rotate to climb attitude. Premature raising on the nose or raising it to an excessive angle will result in a delayed takeoff. After takeoff, let the airplane accelerate to the desired climb speed by lowering the nose slightly.

Takeoffs are normally made with flaps up; however, for short field takeoffs and for takeoffs under difficult conditions such as deep grass or a soft surface, total distances can be reduced appreciably by lowering the flaps to 25° and rotating at lower airspeed.

A short field takeoff with an obstacle clearance is accomplished by first lowering the flaps to 25°. Apply full power before brake release and accelerate to 52 KIAS and rotate. Maintain 52 KIAS until obstacle clearance is attained. After the obstacle has been cleared, accelerate to 75 KIAS and then slowly retract the flaps.

A short field takeoff with no obstacle is accomplished with no flaps and applying full power before brake release, lift off at 50 KIAS and accelerate to best rate of climb speed, 75 KIAS.

Takeoff from a soft field with an obstacle clearance requires the use of 25° flaps. Accelerate the airplane and lift the nose gear off as soon as possible and lift off at the lowest possible airspeed. Accelerate just above the ground to 52 KIAS to climb past obstacle clearance height. Continue climbing while accelerating to the best rate of climb speed, 75 KIAS and slowly retract the flaps.

For a soft field takeoff without an obstacle to clear, extend the flaps 25°, accelerate the airplane and lift the nose gear off as soon as possible. Lift off at the lowest possible airspeed. Accelerate just above the ground to the best rate of climb speed, 75 KIAS and retract the flaps while climbing out.

4.25 CLIMB

The best rate of climb at gross weight will be obtained at 75 KIAS. The best angle of climb may be obtained at 63 KIAS. At lighter than gross weight these speeds are reduced somewhat. For climbing en route, a speed of 87 KIAS is recommended. This will produce better forward speed and increased visibility over the nose during the climb.

When reaching the desired altitude, the electric fuel pump may be turned off.

4.27 CRUISING

The cruising speed of the Cherokee Warrior is determined by many factors, including power setting, altitude, temperature, loading and equipment installed in the airplane.

The normal maximum cruising power is 75% of the rated horsepower of the engine. Airspeeds which may be obtained at various altitudes and power settings can be determined from the performance graphs provided by Section 5.

Use of the mixture control in cruising flight reduces fuel consumption significantly, especially at higher altitudes, and reduces lead deposits when the alternate fuels are used. During letdown and low power flight operations, it may be necessary to lean because of excessively rich mixture. The mixture should be leaned during cruising operation above 5000 feet altitude and when 75% power or less is being used. If any doubt exists as to the amount of power being used, the mixture should be in the FULL RICH position for all operations under 5000 feet. Always enrich the mixture before increasing power settings.

To lean the mixture, disengage the lock and pull the mixture control until the engine becomes rough, indicating that the lean mixture limit has been reached in the leaner cylinders. Then enrich the mixture by pushing the control towards the instrument panel until engine operation becomes smooth. When leaning, carefully observe the temperature instruments.

Always remember that the electric fuel pump should be turned "ON" before switching tanks, and should be left on for a short period thereafter. In order to keep the airplane in best lateral trim during ~~X~~ cruising flight, the fuel should be used alternately from each tank. It is recommended that one tank be used for one hour after takeoff, then the other tank be used for two hours; then return to the first tank, which will have approximately one and one half hours of fuel remaining if the tanks were full at takeoff. The second tank will contain approximately one half hour of fuel. Do not run tanks completely dry in flight. The electric fuel pump should be normally "OFF" so that any malfunction of the engine driven fuel pump is immediately apparent. If signs of fuel starvation should occur at any time during flight, fuel exhaustion should be suspected, at which time the fuel selector should be immediately positioned to the other tank and the electric fuel pump switched to the "ON" position.

4.29 APPROACH AND LANDING

Check to insure the fuel selector is on the proper (fullest) tank and that the seat backs are erect. The seat belts and shoulder harness should be fastened and the inertia reel checked.

Turn "ON" the electric fuel pump. The mixture should be set in the full "RICH" position.

The airplane should be trimmed to an initial approach speed of about 70 KIAS with a final approach speed of 63 KIAS with flaps extended. The approach speed can be reduced approximately 3 KTS for each additional notch of flaps. The flaps can be lowered at speeds up to 103 KIAS, if desired.

The mixture control should be kept in full "RICH" position to insure maximum acceleration if it should be necessary to open the throttle again. Carburetor heat should not be applied unless there is an indication of carburetor icing, since the use of carburetor heat causes a reduction in power which may be critical in case of a go-around. Full throttle operation with carburetor heat on can cause detonation.

The amount of flap used during landings and the speed of the aircraft at contact with the runway should be varied according to the landing surface and conditions of wind and airplane loading. It is generally good practice to contact the ground at the minimum possible safe speed consistent with existing conditions.

Normally, the best technique for short and slow landings is to use full flap and enough power to maintain the desired airspeed and approach flight path. Mixture should be full "RICH," fuel on the fullest tank, and electric fuel pump "ON." Reduce the speed during the flareout and contact the ground close to the stalling speed. After ground contact hold the nose wheel off as long as possible. As the airplane slows down, gently lower the nose and apply the brakes. Braking is most effective when flaps are raised and back pressure is applied to the control wheel, putting most of the aircraft weight on the main wheels. In high wind conditions, particularly in strong crosswinds, it may be desirable to approach the ground at higher than normal speeds with partial or no flaps.

4.31 STOPPING ENGINE

At the pilot's discretion, the flaps should be raised and the electric fuel pump turned "OFF." The radios should be turned "OFF," and the engine stopped by disengaging the mixture control lock and pulling the mixture control back to idle cut-off. The throttle should be left full aft to avoid engine vibration while stopping. Then the magneto and master switches must be turned "OFF."

NOTE

When alternate fuels are used, the engine should be run up to 1200 RPM for one minute prior to shutdown to clean out any unburned fuel.

4.33 PARKING

If necessary, the airplane should be moved on the ground with the aid of the nose wheel tow bar provided with each airplane and secured behind the rear seats. The aileron and stabilator controls should be secured by looping the safety belt through the control wheel and pulling it snug. The flaps are locked when in the "UP" position and should be left retracted.

Tie downs can be secured to rings provided under each wing and to the tail skid. The rudder is held in position by its connections to the nose wheel steering and normally does not have to be secured.

4.35 STALLS

The stall characteristics of the Cherokee Warrior are conventional. An approaching stall is indicated by a stall warning horn which is activated between five and ten KTS above stall speed. Mild airframe buffeting and gentle pitching may also precede the stall.

The gross weight stalling speed of the Cherokee Warrior with power off and full flaps is 44 KIAS. With the flaps up this speed is increased. Loss of altitude during stalls varies from 100 to 275 feet, depending on configuration and power.

NOTE

The stall warning system is inoperative with the master switch "OFF."

During preflight, the stall warning system should be checked by turning the master switch "ON," lifting the detector and checking to determine if the horn is actuated. The master switch should be returned to the "OFF" position after the check is complete.

4.37 TURBULENT AIR OPERATION

In keeping with good operating practice used in all aircraft, it is recommended that when turbulent air is encountered or expected, the airspeed be reduced to maneuvering speed to reduce the structural loads caused by gusts and to allow for inadvertent speed build-ups which may occur as a result of the turbulence or of distractions caused by the conditions. (See Subsection 2.3.)

4.39 WEIGHT AND BALANCE

| It is the responsibility of the pilot to determine that the airplane remains within the allowable weight vs. center of gravity envelope while in flight.

For weight and balance data, refer to Section 6 (Weight and Balance).

TABLE OF CONTENTS

SECTION 5

PERFORMANCE

Paragraph No.		Page No.
5.1	General	5-1
5.3	Introduction to Performance and Flight Planning	5-1
5.5	Flight Planning Example	5-3
5.7	Performance Graphs	5-9
	List of Figures	5-9

**SECTION 5
PERFORMANCE**

5.1 GENERAL

All of the required (FAA regulations) and complementary performance information applicable to the Cherokee Warrior is provided in this section.

Performance information associated with those optional systems and equipment which require handbook supplements is provided in Section 9 (Supplements).

5.3 INTRODUCTION TO PERFORMANCE AND FLIGHT PLANNING

The performance information presented in this section is based on measured flight test data corrected to I.C.A.O. standard day conditions and analytically expanded for the various parameters of weight, altitude, temperature, etc.

The performance charts are unfactored and do not make any allowance for varying degrees of pilot proficiency or mechanical deterioration of the aircraft. This performance, however, can be duplicated by following the stated procedures in a properly maintained airplane.

Effects of conditions not considered on the charts must be evaluated by the pilot, such as the effect of soft or grass runway surface on takeoff and landing performance, or the effect of winds aloft on cruise and range performance. Endurance can be grossly affected by improper leaning procedures, and inflight fuel flow and quantity checks are recommended.

REMEMBER! To get chart performance, follow the chart procedures.

The information provided by paragraph 5.5 (Flight Planning Example) outlines a detailed flight plan using the performance charts in this section. Each chart includes its own example to show how it is used.

WARNING

Performance information derived by extrapolation beyond the limits shown on the charts should not be used for flight planning purposes.

THIS PAGE INTENTIONALLY LEFT BLANK

5.5 FLIGHT PLANNING EXAMPLE

(a) Aircraft Loading

The first step in planning the flight is to calculate the airplane weight and center of gravity by utilizing the information provided by Section 6 (Weight and Balance) of this handbook.

The basic empty weight for the airplane as licensed at the factory has been entered in Figure 6-5. If any alterations to the airplane have been made effecting weight and balance, reference to the aircraft logbook and Weight and Balance Record (Figure 6-7) should be made to determine the current basic empty weight of the airplane.

Make use of the Weight and Balance Loading Form (Figure 6-11) and the C.G. Range and Weight graph (Figure 6-15) to determine the total weight of the airplane and the center of gravity position.

After proper utilization of the information provided, the following weights have been determined for consideration in the flight planning example.

The landing weight cannot be determined until the weight of the fuel to be used has been established [refer to item (g)(1)].

(1) Basic Empty Weight	1391 lbs.
(2) Occupants (4 x 170 lbs.)	680 lbs.
(3) Baggage and Cargo	50 lbs.
(4) Fuel (6 lb/gal x 30)	180 lbs.
(5) Takeoff Weight	2316 lbs.
(6) Landing Weight	
(a)(5) minus (g)(1), (2316 lbs. minus 145.2 lbs.)	2170.8 lbs.

The takeoff weight is below the maximum of 2325 lbs. and the weight and balance calculations have determined the C.G. position within the approved limits.

(b) Takeoff and Landing

After determining aircraft loading, all takeoff and landing aspects must be considered.

All of the existing conditions at the departure and destination airport must be acquired, evaluated and maintained throughout the flight.

Apply the departure airport conditions and takeoff weight to the appropriate Takeoff Performance graph (Figure 5-5 or 5-7), to determine the length of runway necessary for the takeoff and/or the barrier distance.

The landing distance calculations are performed in the same manner using the existing conditions at the destination airport and, when established, the landing weight.

SECTION 5
PERFORMANCE

PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR

The conditions and calculations for the example flight are listed below. The takeoff and landing distances required for the example flight have fallen well below the available runway lengths.

	Departure Airport	Distination Airport
(1) Pressure Altitude	1500 ft.	2500 ft.
(2) Temperature	80° F	75° F
(3) Wind Component	15 KTS	0 KTS
(4) Runway Length Available	4800 ft.	7600 ft.
(5) Runway Required	1200 ft.*	660**

NOTE

The remainder of the performance charts used in this flight plan example assume no wind condition. The effect of winds aloft must be considered by the pilot when computing climb, cruise and descent performance.

(c) Climb

The next step in flight planning is to determine the necessary climb segment components.

The desired cruise pressure altitude and corresponding cruise outside air temperature values are the first variables to be considered in determining the climb components from the Time, Distance, and Fuel to Climb graph (Figure 5-13). After the time, distance and fuel for the cruise pressure altitude and outside air temperature values have been established, apply the existing conditions at the departure field to graph (Figure 5-13). Now, subtract the values obtained from the graph for the field of departure conditions from those for the cruise pressure altitude.

The remaining values are the true fuel, distance and time components for the climb segment of the flight plan corrected for field pressure altitude and temperature.

The following values were determined from the above instructions in the flight planning example.

(1) Cruise Pressure Altitude	5000 ft.
(2) Cruise OAT	60° F
(3) Time to Climb (12.5 min. minus 5.5 min.)	7 min.***
(4) Distance to Climb (16.5 miles minus 7.5 miles)	9 miles***
(5) Fuel to Climb (2.5 gal. minus 1.5 gal.)	1 gal.***

*reference Figure 5-5

**reference Figure 5-27

***reference Figure 5-13

(d) Descent

The descent data will be determined prior to the cruise data to provide the descent distance for establishing the total cruise distance.

Utilizing the cruise pressure altitude and OAT, determine the basic time, distance, and fuel for descent (Figure 5-23). These figures must be adjusted for the field pressure altitude and temperature at the destination airport. To find the necessary adjustment values, use the existing pressure altitude and temperature conditions at the destination airport as variables to find the time, distance, and fuel values from the graph (Figure 5-23). Now, subtract the values obtained from the field conditions from the values obtained from the cruise conditions to find the true time, distance, and fuel values needed for the flight plan.

The values obtained by proper utilization of the graphs for the descent segment of the example are shown below.

(1) Time to Descent (7.5 min. minus 5.5 min.)	2.0 min.*
(2) Distance to Descend (17.0 miles minus 12.0 miles)	5 miles*
(3) Fuel to Descent (1.5 gal. minus 1 gal.)	.5 gal.*

(e) Cruise

Using the total distance to be traveled during the flight, subtract the previously calculated distance to climb and distance to descend to establish the total cruise distance. Refer to the appropriate Avco Lycoming Operator's Manual when selecting the cruise power setting. The established pressure altitude and temperature values and the selected cruise power should now be utilized to determine the true airspeed from the Cruise Performance graph (Figure 5-15 or 5-17).

Calculate the cruise fuel flow for the cruise power setting from the information provided by the Avco Lycoming Operator's Manual.

The cruise time is found by dividing the cruise distance by the cruise speed and the cruise fuel is found by multiplying the cruise fuel flow by the cruise time.

The cruise calculations established for the cruise segment of the flight planning example are as follows:

(1) Total Distance	300 miles
(2) Cruise Distance	
(e)(1) minus (c)(4) minus (d)(2), (300 miles minus 9 miles minus 5 miles)	286 miles
(3) Cruise Power, Best Economy Mixture	75% rated power (2645 RPM)
(4) Cruise Speed	107 KTS TAS**
(5) Cruise Fuel Consumption	8.4 GPH
(6) Cruise Time	
(e)(2) divided by (e)(4), (286 miles divided by 107 KTS)	2.7 hrs.
(7) Cruise Fuel	
(e)(5) multiplied by (e)(6), (8.4 GPH multiplied by 2.67 hrs.)	22.7 gal.

*reference Figure 5-23

**reference Figure 5-17

(f) Total Flight Time

The total flight time is determined by adding the time to climb, the time to descend and the cruise time. Remember! The time values taken from the climb and descent graphs are in minutes and must be converted to hours before adding them to the cruise time.

The following flight time is required for the flight planning example.

(1) Total Flight Time

(c)(3) plus (d)(1) plus (e)(6), (.12 hrs. plus .033 hrs. plus 2.7 hrs.) 2.85 hrs.

(g) Total Fuel Required

Determine the total fuel required by adding the fuel to climb, the fuel to descent and the cruise fuel. When the total fuel (in gallons) is determined, multiply this value by 6 lb/gal to determine the total fuel weight used for the flight.

The total fuel calculations for the example flight plan are shown below.

(1) Total Fuel Required

(c)(5) plus (d)(3) plus (e)(7), (1 gal. plus .5 gal. plus 22.7 gal.) 24.2 gal.
(24.2 gal. multiplied by 6 lb/gal.) 145.2 lbs.

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK


5.7 PERFORMANCE GRAPHS

LIST OF FIGURES

Figure No.		Page No.
5-1	Airspeed System Calibration	5-11
5-3	Stall Speed	5-12
5-5	Normal Short Field Takeoff Distance - No Obstacle	5-13
5-7	Obstacle Clearance Short Field Takeoff Distance	5-14
5-9	Engine Performance	5-15
5-11	Climb Performance	5-16
5-13	Time, Distance and Fuel to Climb	5-17
5-15	Best Power Cruise Performance	5-18
5-17	Best Economy Cruise Performance	5-19
5-19	Best Economy Mixture Range	5-20
5-21	Endurance	5-21
5-23	Time, Distance and Fuel to Descend	5-22
5-25	Glide Performance	5-23
5-27	Landing Performance	5-24

THIS PAGE INTENTIONALLY LEFT BLANK


PA-28-151



AIRSPEED SYSTEM CALIBRATION

Figure 5-1

PA-28-151




Example:
Gross weight: 2170 lbs.
Angle of bank: 20°
Flap position: 40°
Stall speed, indicated: 44 knots

STALL SPEED

Figure 5-3

PA-28-151




Example:

Departure airport pressure altitude: 1500 ft.
Departure airport temperature: 80°F
Wind: 15 KTS headwind
Ground roll: 1200 ft.
Distance over 50 ft. barrier: 2650 ft.

NORMAL SHORT FIELD TAKEOFF DISTANCE - NO OBSTACLE

Figure 5-5

PA-28-151




Example:

Departure airport pressure altitude: 1500 ft.
Departure airport temperature: 80°F
Wind: 15 KTS headwind
Ground roll: 1600 ft.
Distance over 50 ft. barrier: 2100 ft.

OBSTACLE CLEARANCE SHORT FIELD TAKEOFF DISTANCE

Figure 5-7

PA-28-151



Example:

Cruise pressure altitude: 5000 ft.

Cruise OAT: 60°F


Cruise power: 75%

Engine RPM: 2645

ENGINE PERFORMANCE

Figure 5-9

PA-28-151



Example:

Climb pressure altitude: 5000 ft.


Climb OAT: 60°F

Rate of climb: 380 ft./min.

CLIMB PERFORMANCE

Figure 5-11

PA-28-151



Example:

Departure airport pressure altitude: 1500 ft.

Departure airport temperature: 80°F

Cruise pressure altitude: 5000 ft.

Cruise OAT: 60°F

Time to climb (12.5 min. minus 5.5 min.): 7 min.


Distance to climb (16.5 miles minus 7.5 miles): 9 nautical miles

Fuel to climb (2.5 gal. minus 1.5 gal.): 1 gal.

TIME, DISTANCE AND FUEL TO CLIMB

Figure 5-13

PA-28-151




Example:

Cruise pressure altitude: 5000 ft.
Cruise OAT: 60°F
Cruise power: 75%, Best Power Mixture
Cruise speed: 113 KTS TAS

BEST POWER CRUISE PERFORMANCE

Figure 5-15

PA-28-151




Example:

Cruise pressure altitude: 5000 ft.
Cruise OAT: 60°F
Cruise power: 75%, Best Economy Mixture
Cruise speed: 107 KTS TAS

BEST ECONOMY CRUISE PERFORMANCE

Figure 5-17

PA-28-151



Example:

Cruise pressure altitude: 5000 ft.

Cruise OAT: 60°F

Cruise power: 75%, Best Economy Mixture


Range with 45 min. reserve at 55% power: 520 nautical miles

Range with no reserve: 583 nautical miles

BEST ECONOMY MIXTURE RANGE

Figure 5-19

PA-28-151




Example:

Cruise pressure altitude: 5000 ft.
Cruise OAT: 60°F
Cruise power: 75%, Best Economy Mixture
Endurance with 45 min. reserve at 55% power: 4.7 hrs.
Endurance with no reserve: 5.5 hrs.

ENDURANCE

Figure 5-21

PA-28-151




Example:

Destination airport pressure altitude: 2500 ft.
 Destination airport temperature: 75°F
 Cruise pressure altitude: 5000 ft.
 Cruise OAT: 60°F
 Time to descend (7.5 min. minus 5.5 min.): 2 min.
 Distance to descend (17 miles minus 12 miles): 5 nautical miles
 Fuel to descend (1.5 gal. minus 1 gal.): .5 gal.

TIME, DISTANCE AND FUEL TO DESCEND

Figure 5-23

PA-28-151



Example:

Cruise pressure altitude: 5000 ft.

Cruise OAT: 28°F

Terrain pressure altitude: 2000 ft.


Temperature at terrain: 50°F

Glide distance (8 miles minus 3.5 miles): 4.5 nautical miles

GLIDE PERFORMANCE

Figure 5-25

PA-28-151



Example:

Destination airport pressure altitude: 2500 ft.

Destination airport temperature: 75°F

Destination airport wind: 0 KTS

Ground roll: 660 ft.

Distance over 50 ft. barrier: 1190 ft.

LANDING PERFORMANCE

Figure 5-27

TABLE OF CONTENTS

SECTION 6

WEIGHT AND BALANCE

Paragraph No.		Page No.
6.1	General	6-1
6.3	Airplane Weighing Procedure	6-3
6.5	Weight and Balance Data and Record	6-6
6.7	Weight and Balance Determination for Flight	6-11
6.9	Equipment List	6-17
(a)	Propeller and Propeller Accessories	6-17
(b)	Engine and Engine Accessories	6-19
(c)	Landing Gear and Brakes	6-21
(d)	Electrical Equipment	6-23
(e)	Instruments	6-25
(f)	Miscellaneous	6-27
(g)	Engine and Engine Accessories (Optional Equipment)	6-29
(h)	Propeller and Propeller Accessories (Optional Equipment)	6-31
(i)	Landing Gear and Brakes (Optional Equipment)	6-33
(j)	Electrical Equipment (Optional Equipment)	6-35
(k)	Instruments (Optional Equipment)	6-37
(l)	Autopilots (Optional Equipment)	6-39
(m)	Radio Equipment (Optional Equipment)	6-41
(n)	Miscellaneous (Optional Equipment)	6-53

**SECTION 6
WEIGHT AND BALANCE**

6.1 GENERAL

In order to achieve the performance and flying characteristics which are designed into the airplane, it must be flown with the weight and center of gravity (C.G.) position within the approved operating range (envelope). Although the airplane offers flexibility of loading, it cannot be flown with the maximum number of adult passengers, full fuel tanks and maximum baggage. With the flexibility comes responsibility. The pilot must ensure that the airplane is loaded within the loading envelope before he makes a takeoff.

Misloading carries consequences for any aircraft. An overloaded airplane will not take off, climb or cruise as well as a properly loaded one. The heavier the airplane is loaded, the less climb performance it will have.

Center of gravity is a determining factor in flight characteristics. If the C.G. is too far forward in any airplane, it may be difficult to rotate for takeoff or landing. If the C.G. is too far aft, the airplane may rotate prematurely on takeoff or tend to pitch up during climb. Longitudinal stability will be reduced. This can lead to inadvertent stalls and even spins; and spin recovery becomes more difficult as the center of gravity moves aft of the approved limit.

A properly loaded airplane, however, will perform as intended. Before the airplane is licensed, it is weighed, and a basic empty weight and C.G. location is computed (basic empty weight consists of the standard empty weight of the airplane plus the optional equipment). Using the basic empty weight and C.G. location, the pilot can easily determine the weight and C.G. position for the loaded airplane by computing the total weight and moment and then determining whether they are within the approved envelope.

The basic empty weight and C.G. location are recorded in the Weight and Balance Data Form (Figure 6-5) and the Weight and Balance Record (Figure 6-7). The current values should always be used. Whenever new equipment is added or any modification work is done, the mechanic responsible for the work is required to compute a new basic empty weight and C.G. position and to write these in the Aircraft Logbook and the Weight and Balance Record. The owner should make sure that it is done.

A weight and balance calculation is necessary in determining how much fuel or baggage can be boarded so as to keep within allowable limits. Check calculations prior to adding fuel to ensure against improper loading.

The following pages are forms used in weighing an airplane in production and in computing basic empty weight, C.G. position, and useful load. Note that the useful load includes usable fuel, baggage, cargo and passengers. Following this is the method for computing takeoff weight and C.G.

THIS PAGE INTENTIONALLY LEFT BLANK

6.3 AIRPLANE WEIGHING PROCEDURE

At the time of licensing, Piper Aircraft Corporation provides each airplane with the basic empty weight and center of gravity location. This data is supplied by Figure 6-5.

The removal or addition of equipment or airplane modifications can affect the basic empty weight and center of gravity. The following is a weighing procedure to determine this basic empty weight and center of gravity location:

(a) Preparation

- (1) Be certain that all items checked in the airplane equipment list are installed in the proper location in the airplane.**
- (2) Remove excessive dirt, grease, moisture, foreign items such as rags and tools from the airplane before weighing.**

CAUTION

Whenever the fuel system is completely drained and fuel is replenished it will be necessary to run the engine for a minimum of 3 minutes at 1000 RPM on each tank to ensure that no air exists in the fuel lines.

- (3) Defuel airplane. Then open all fuel drains until all remaining fuel is drained. Operate engine on each tank until all undrainable fuel is used and engine stops. Then add the unusable fuel (2.0 gallons total, 1.0 gallon each wing).**
 - (4) Fill with oil to full capacity.**
 - (5) Place pilot and copilot seats in fourth (4th) notch, aft of forward position. Put flaps in the fully retracted position and all control surfaces in the neutral position. Tow bar should be in the proper location and all entrance and baggage doors closed.**
 - (6) Weigh the airplane inside a closed building to prevent errors in scale readings due to wind.**
- (b) Leveling**
- (1) With airplane on scales, block main gear oleo pistons in the fully extended position.**
 - (2) Level airplane (refer to Figure 6-3) deflating nose wheel tire, to center bubble on level.**

(c) Weighing - Airplane Basic Empty Weight

- (1) With the airplane level and brakes released, record the weight shown on each scale. Deduct the tare, if any, from each reading.


Scale Position and Symbol	Scale Reading	Tare	Net Weight
Nose Wheel (N)			
Right Main Wheel (R)			
Left Main Wheel (L)			
Basic Empty Weight, as Weighed (T)	—	—	

WEIGHING FORM

Figure 6-1

(d) Basic Empty Weight Center of Gravity

- (1) The following geometry applies to the PA-28-151 airplane when it is level. Refer to Leveling paragraph 6.3 (b).



A = 30.9

B = 109.7

LEVELING DIAGRAM

Figure 6-3

- (2) The basic empty weight center of gravity (as weighed including optional equipment, full oil and unusable fuel) can be determined by the following formula:

$$\text{C.G. Arm} = \frac{N(A) + (R + L)(B)}{T} \text{ inches}$$

Where: $T = N + R + L$

6.5 WEIGHT AND BALANCE DATA AND RECORD

The Basic Empty Weight, Center of Gravity Location and Useful Load listed in Figure 6-5 are for the airplane as licensed at the factory. These figures apply only to the specific airplane serial number and registration number shown.

The basic empty weight of the airplane as licensed at the factory has been entered in the Weight and Balance Record (Figure 6-7). This form is provided to present the current status of the airplane basic empty weight and a complete history of previous modifications. Any change to the permanently installed equipment or modification which affects weight or moment must be entered in the Weight and Balance Record.

MODEL PA-28-151 CHEROKEE WARRIOR

Airplane Serial Number 28-7715251

Registration Number N 7963F

Date 11/19/76

AIRPLANE BASIC EMPTY WEIGHT

Item	Weight (Lbs)	x C.G. Arm (Inches Aft of Datum)	= Moment (In-Lbs)
Standard Empty Weight* Actual Computed	<u>1335</u>	<u>84.9</u>	<u>113301</u>
Optional Equipment	<u>119.1</u>	<u>107.9</u>	<u>12851</u>
Basic Empty Weight	<u>1454.1</u>	<u>86.8</u>	<u>126152</u>

*The standard empty weight includes full oil capacity and 2.0 gallons of unusable fuel.

AIRPLANE USEFUL LOAD - NORMAL CATEGORY OPERATION

(Gross Weight) - (Basic Empty Weight) = Useful Load

Normal Category: (2325 lbs) - (1454.1 lbs) = 870.9 lbs.

Utility Category: (1950 lbs) - (1454.1 lbs) = 495.9 lbs.

THIS BASIC EMPTY WEIGHT, C.G. AND USEFUL LOAD ARE FOR THE AIRPLANE AS LICENSED AT THE FACTORY. REFER TO APPROPRIATE AIRCRAFT RECORD WHEN ALTERATIONS HAVE BEEN MADE.

WEIGHT AND BALANCE DATA FORM
Figure 6-5

THIS PAGE INTENTIONALLY LEFT BLANK

WEIGHT AND BALANCE RECORD

Figure 6-7

SECTION 6

WEIGHT AND BALANCE

**PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR**

[illegible]

WEIGHT AND BALANCE RECORD

Figure 6-7 (cont)

6.7 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT

- Add the weight of all items to be loaded to the basic empty weight.
- Use the Loading Graph (Figure 6-13) to determine the moment of all items to be carried in the airplane.
- Add the amount of all items to be loaded to the basic empty weight moment.
- Divide the total moment by the total weight to determine the C.G. location.
- By using the figures of item (a) and item (d) (above), locate a point on the C.G. range and weight graph (Figure 6-15). If the point falls within the C.G. envelope, the loading meets the weight and balance requirements.

	Weight (Lbs)	Arm Aft Datum (Inches)	Moment (In-Lbs)
Basic Empty Weight	1454.1	86.3	126152
Pilot and Front Passenger	340.0	80.5	27370
Passengers (Rear Seats)*	340.0	118.1	40154
Fuel (48 Gallon Maximum)	190.9	95.0	18136
Baggage*		142.8	
Total Loaded Airplane	2325	91.1	211812

The center of gravity (C.G.) of this sample loading problem is at _____ inches aft of the datum line. Locate this point () on the C.G. range and weight graph. Since this point falls within the weight - C.G. envelope, this loading meets the weight and balance requirements.

IT IS THE RESPONSIBILITY OF THE PILOT TO ENSURE THAT THE AIRPLANE IS LOADED PROPERLY.

*Utility Category Operation - No baggage or aft passengers allowed.

SAMPLE LOADING PROBLEM (NORMAL CATEGORY)

Figure 6-9

SECTION 6
WEIGHT AND BALANCE


PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR

	Weight (Lbs)	Arm Aft Datum (Inches)	Moment (In-Lbs)
Basic Empty Weight			
Pilot and Front Passenger		80.5	
Passengers (Rear Seats)*		118.1	
Fuel (48 Gallon Maximum)		95.0	
Baggage*		142.8	
Total Loaded Airplane			

Totals must be within approved weight and C.G. limits. It is the responsibility of the pilot to ensure that the airplane is loaded properly. The Basic Empty Weight C.G. is noted on the Weight and Balance Data Form (Figure 6-5). If the airplane has been altered, refer to the Weight and Balance Record for this information.


*Utility Category Operation - No baggage or aft passengers allowed.

WEIGHT AND BALANCE LOADING FORM
Figure 6-11



LOADING GRAPH

Figure 6-13



C. G. RANGE AND WEIGHT

Figure 6-15

Good Fuel 6635

Aircraft Make	Aircraft Model	Serial #	Reg. #
PIPER	PA-28-151	28-7715251	N7963F
Owners Name		Owners Address	
Category	Empty Weight Pounds	Empty Weight C.G.	Useful Load
NORMAL	1477	86.46	848
Installation Date		Moment	Work Order #
		127710.4	

LIST OF EQUIPMENT INSTALLED OR REMOVED

ITEM NO.	REM.	INST.	ITEM DESCRIPTION	CURRENT
1		X	KING KA-134 AUDIO AMP	
2		X	KING KX-155 NAV/COM/GS.	
3		X	KING KI-209 IND	
4		X	KING KR-87 ADF REC.	
5		X	KING KI-227 ADF IND.	
6		X	KING KA-44B ADF ANT	
7		X	APOLLO 612 LORAN REC.	
8		X	Com ANT	
9		X	LORAN ANT	
10		X	NARCO AR-500 ENCODER	
11		X	ARC 402 MARKER REC.	
12		X	KING KN-64 DME	
13				
14				
15				
16				
17				
18				
19				
20				
21				

EQUIPMENT WEIGHT AND LOCATION

ITEM NO.	WEIGHT	ARM	MOMENT	LOCATION
1	.8	60.2	48.16	
2	5.3	57.5	304.75	
3	1.2	59.0	70.8	
4	3.2	57.5	184.0	
5	.7	60.0	42.0	
6	2.0	108.0	216.0	
7	3.7	57.0	210.9	
8	.8	147	117.6	
9	.7	159	111.3	
10	.8	55	44.0	
11	1.1	54	59.4	
12	2.6	57.5	149.5	
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				

REMARKS:

Date _____ Signed _____
for FAA approved repair station #C08-16
General Aviation, Inc., Capital City Airport, Lansing, MI 48906

6.9 EQUIPMENT LIST

The following is a list of equipment which may be installed in the airplane. Items marked with an "X" were installed on the airplane described below when licensed by the manufacturer. Piper Aircraft Corporation will not revise this equipment list once the aircraft is licensed. It is the owner's responsibility to retain this equipment list and to amend it to reflect changes in equipment installed in this airplane.

Unless otherwise indicated, the installation certification basis for the equipment included in this list is the aircraft's approved type design.

PIPER AIRCRAFT CORPORATION

PA-28-151 CHEROKEE WARRIOR

SERIAL NO. _____ REGISTRATION NO. _____ DATE: _____

(a) Propeller and Propeller Accessories

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
1	Propeller, Sensenich 74DM6-0-58 Cert. Basis - TC P886	<u>✓</u>	31.6	3.8	120
2	Propeller, McCauley 1C160EGM7653 Cert. Basis - TC P910	<u> </u>	30.6	3.8	116

THIS PAGE INTENTIONALLY LEFT BLANK

(b) Engine and Engine Accessories

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
5	Lycoming Model O-320-E3D Cert. Basis - TC 274				
7	Alternator 60 Amp Prestolite No. ALY6408 Cert. Basis - TC 2A13	_____	10.5	14.0	147
9	Alternator 60 Amp Chrysler 3656623 Cert. Basis - TC 2A13	_____	12.4	14.0	174

THIS PAGE INTENTIONALLY LEFT BLANK

(c) Landing Gear and Brakes

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
13	Two Main Wheel Assemblies				
	a. Cleveland Aircraft Products				
	Wheel Assy. No. 40-86				
	Brake Assy. No. 30-55				
	Cert. Basis - TSO C26a				
	b. 6.00-6 Type III 4 Ply				
	Rating Tires with Regular Tubes				
	Cert. Basis - TSO C62				
15	Nose Wheel Assembly				
	a. Cleveland Aircraft Products				
	Wheel Assy. No. 40-77A				
	Cert. Basis - TSO C26a				
	b. 5.00-5 Type III 4 Ply				
	Rating Tire with Regular Tube				
	Cert. Basis - TSO C62				

THIS PAGE INTENTIONALLY LEFT BLANK

(d) Electrical Equipment

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
-------------	------	-------------------	--------------------	------------------------	--------------------

THIS PAGE INTENTIONALLY LEFT BLANK

(c) Instruments

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
21	Altimeter. Piper PS50008-2 or -3 Cert. Basis - TSO C10b				
23	Airspeed Indicator Piper PS50049-29S Cert. Basis - TSO C2b				
25	Compass Piper Dwg. 67462 Cert. Basis - TSO C7c				

THIS PAGE INTENTIONALLY LEFT BLANK

(f) Miscellaneous

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
33	Front Seat Belts (2) Piper PS50039-4-2A Cert. Basis - TSO C22f				
35	Aft Seat Belts (2) Piper PS50039-4-3 Cert. Basis - TSO C22f				

**SECTION 6
WEIGHT AND BALANCE**

**PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR**

THIS PAGE INTENTIONALLY LEFT BLANK

(g) Engine and Engine Accessories
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
45	Primer System Piper Dwg. 35327-0 Cert. Basis - TC 2A13	<u>X</u>	1.2	50.0	60
47	Starter - Lycoming 76211 Prestolite MZ4206 Cert. Basis - TC 274	<u> </u>	*1.0	14.5	15

*Weight and moment difference between standard and optional equipment.

THIS PAGE INTENTIONALLY LEFT BLANK

(h) Propeller and Propeller Accessories
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
-------------	------	-------------------	--------------------	------------------------	--------------------

THIS PAGE INTENTIONALLY LEFT BLANK

(i) Landing Gear and Brakes
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
63	Nose Wheel Fairing Piper Dwg. 35513 Cert. Basis - TC 2A13	<u>X</u>	3.8	29.8	113
65	Main Wheel Fairings Piper Dwg. 65237 Cert. Basis - TC 2A13	<u>X</u>	7.6	113.6	863

THIS PAGE INTENTIONALLY LEFT BLANK

(j) Electrical Equipment
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
		X			
79	Instrument Panel Lights Cert. Basis - TC 2A13	_____	0.3	67.8	20
81	Instrument Light (2). Grimes 15-0083-7 Cert. Basis - TC 2A13	_____	0.1	99.0	10
83	Cabin Light Cert. Basis - TC 2A13	_____	0.3	99.0	30
85	Landing Light, G.E. Model 4509 Cert. Basis - TC 2A13	_____	0.5	13.1	7
87	Navigation Lights (2) Grimes Model A1285 (Red and Green) Cert. Basis - TC 2A13	_____	0.4	106.6	43
89	Navigation Light (Rear) (1) Grimes Model A2064 (White) Cert. Basis - TC 2A13	_____	0.2	281.0	56
91	Rotating Beacon Cert. Basis - TC 2A13	_____	1.5	263.4	395
93	Anti-Collision Lights (Fin only) Piper Dwg. 99033-7 Cert. Basis - TC 2A13	_____	3.1	210.3	652
95	Anti-Collision Lights (Fin and Wing Tips) Piper Dwg. 99033-10 Cert. Basis - TC 2A13	_____	6.1	172.8	1054
97	Heated Pitot Head. Piper Dwg. 35493-2 Cert. Basis - TC 2A13	_____	0.4	100.0	40

SECTION 6
WEIGHT AND BALANCE

PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR

(j) Electrical Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
99	Piper Pitch Trim Piper Dwg. 67496-3 Cert. Basis - TC 2A13	<input checked="" type="checkbox"/>	4.3	155.3	668
101	Battery 12V 35 A.H. Rebat R35 (Wt. 27.2 lbs.) Cert. Basis - TC 2A13	<input checked="" type="checkbox"/>	*5.3	114.9	609
103	Auxiliary Power Receptacle, Piper Dwg. 35289 Cert. Basis - TC 2A13	<input checked="" type="checkbox"/>	2.7	178.5	482
105	External Power Cable, Piper Dwg. 62355-11 Cert. Basis - TC 2A13		4.6	142.8	657
107	Lighter, *200462, 12 Volt Universal Cert. Basis - TC 2A13	<input checked="" type="checkbox"/>	.2	62.9	13

*Weight and moment difference between standard and optional equipment.

(k) Instruments
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
113	Vacuum System Installation Cert. Basis - TC 2A13	<u>X</u>	4.5	39.1	176
115	Attitude Gyro, Piper Dwg. 99002-2, -3, -4 or -5 Cert. Basis - TSO C4c	<u>X</u>	2.2	59.4	131
117	Directional Gyro, Piper Dwg. 99003-2, -3, -4 or -5 Cert. Basis - TSO C5c	<u>X</u>	2.6	59.7	155
119	Tru-Speed Indicator, Piper PS50049-29T Cert. Basis - TSO C2b	<u>X</u>	(same as standard equipment)		
121	Encoding Altimeter, Piper PS50008-6 or -7 Cert. Basis - TSO C10b, C88	<u>X</u>	* .9	60.3	54
123	Vertical Speed Piper Dwg. 99010-2, -4 or -5 Cert. Basis - TSO C8b	<u>X</u>	1.0	60.9	61
125	Alternate Static Source Cert. Basis - TC 2A13	<u>X</u>	.4	61.0	24
127	Turn and Slip Indicator, Piper PS50030-2 or -3 Cert. Basis - TSO C3b	<u>X</u>	2.6	59.7	155

*Weight and moment difference between standard and optional equipment.

SECTION 6
WEIGHT AND BALANCE

PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR

(k) Instruments
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
129	Engine Hour Meter Piper Dwg. 69889-0 Cert. Basis - TC 2A13	<u> </u>	0.3	61.2	18
131	Clock Cert. Basis - TC 2A13	<u> X </u>	.4	62.4	25
133	Air Temperature Gauge, Piper Dwg. 99479-0 or -2 Cert. Basis - TC 2A13	<u> X </u>	.2	72.6	15

(I) Autopilots
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
147	AutoFlite II Cert. Basis - STC SA3066SW-D	_____	5.6	91.8	514
149	AutoControl IIIB a. Omni Coupler 1C-388 Cert. Basis - STC SA 3065SW-D	_____ _____	9.6 1.0	77.6 59.3	745 59

THIS PAGE INTENTIONALLY LEFT BLANK

(m) Radio Equipment
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
161	Collins VHF-251 Comm Transceiver				
	a. Single	_____	3.4	56.9	193
	b. Dual	_____	6.8	56.9	387
	Cert. Basis - TSO C37b, C38b				
163	Collins VIR-351 Nav Receiver				
	a. Single	_____	2.7	57.4	155
	b. Dual	_____	5.4	57.4	310
	Cert. Basis - TSO C40a, C36c				
165	Collins IND-350 VOR/LOC Indicator				
	a. Single	_____	1.0	60.2	60
	b. Dual	_____	2.0	60.2	120
	Cert. Basis - TSO C40a, C36c				
167	Collins IND-351 VOR/LOC/ GS Indicator				
	Cert. Basis - TSO C40a, C36c	_____	1.3	60.2	78
169	Collins GLS-350 Glide Slope Receiver				
	Cert. Basis - TSO C34c	_____	2.0	183.4	367
171	Collins RCR-650 ADF Receiver and Antenna and IND-650 Indicator				
	Cert. Basis - TSO C41c	_____	6.6	104.8	692

SECTION 6
WEIGHT AND BALANCE

PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
173	Collins AMR-350 Audio/Marker Panel Cert. Basis - TSO C35d, C50b	_____	*3.3	110.0	363
175	Collins TDR-950 Transponder Cert. Basis - TSO C74c	_____	**2.8	62.9	176

*Weight includes antenna and cable.

**Weight includes antenna.

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
177	King KX 170 () VHF Comm/Nav	X			
	a. Transceiver, Single	_____	7.5	56.6	425
	b. Transceiver, Dual	_____	15.0	56.6	849
	Cert. Basis - TC 2A13				
179	King KX 175 () VHF				
	a. Transceiver,	_____	9.4	56.6	532
	b. King KN 73 Glide Slope Receiver,	_____	3.2	184.3	590
	c. King KN 77 VOR/LOC Converter,	_____	3.6	183.6	661
	d. King KNI 520 VOR/ILS Indicator	_____	1.7	60.5	103
	Cert. Basis - TSO C3bc, C37b, C38b, C40a				
181	King KX 175 () VHF				
	a. Transceiver (2nd),	_____	8.6	56.6	487
	b. King KN 77 VOR/LOC Converter,	_____	4.2	183.6	771
	c. King KNI 520 VOR/ILS Indicator	_____	1.7	60.5	103
	Cert. Basis - TSO C36c, C37b, C38b, C40a				
183	King KI 201 () VOR/LOC Ind.	X			
	a. Single	_____	2.5	59.6	149
	b. Dual	_____	5.0	59.9	300
	Cert. Basis - TC 2A13				
185	King KI 213 VOR/LOC/GS Indicator				
	Cert. Basis - TC 2A13	_____	2.5	60.4	151
187	King KI 214 () VOR/LOC/GS Ind.				
	Cert. Basis - TC 2A13	_____	3.3	59.9	198

SECTION 6
WEIGHT AND BALANCE

PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
189	King KN 74 R-Nav Cert. Basis - TC 2A13	_____	4.7	56.6	266
191	King KN 61 DME Cert. Basis - TC 2A13	_____	12.5	179.0	2237
193	King KN 65A DME Cert. Basis - TSO C66a	_____	13.0	174.9	2274
195	King KR 85 Digital ADF a. Audio Amplifier Cert. Basis - TSO C41b	_____ _____	8.6 0.8	85.2 51.0	733 41
197	King KR 86 ADF a. First b. Second c. Audio Amplifier Cert. Basis - TC 2A13	_____ _____ _____	6.7 9.7 0.8	91.6 107.0 51.0	614 1038 41
199	King KMA 20 () Audio Panel Cert. Basis - TSO C35c, C50b	_____	*3.7	70.8	262
201	King KT 76/78 Transponder Cert. Basis - TSO C74b	X _____	*3.1	58.1	180

895 / 304
695

*Weight includes antenna and cable.

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
203	Narco Comm 10A VHF Transceiver Cert. Basis - TC 2A13	_____	3.9	57.4	224
205	Narco Comm 11A VHF Transceiver				
	a. Single	_____	3.6	57.4	207
	b. Dual	_____	7.1	57.4	408
	Cert. Basis - TC 2A13				
207	Narco Comm 11B VHF Transceiver				
	a. Single	_____	3.9	57.4	224
	b. Dual	_____	7.8	57.4	448
	Cert. Basis - TC 2A13				
209	Narco Comm 111 VHF Transceiver				
	a. Single	_____	3.0	57.4	172
	b. Dual	_____	6.0	57.4	344
	Cert. Basis - TSO C37b, C38b				
211	Narco Comm IIIB VHF Transceiver				
	a. Single	_____	3.9	57.4	224
	b. Dual	_____	7.8	57.4	448
	Cert. Basis - TSO C37b, C38b				
213	Narco Nav 10 VHF Receiver Cert. Basis - TC 2A13	_____	1.9	58.6	111
215	Narco Nav 11 VHF Receiver				
	a. Single	_____	2.8	58.6	164
	b. Dual	_____	5.6	58.6	328
	Cert. Basis - TC 2A13				

SECTION 6
WEIGHT AND BALANCE

PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
217	Narco Nav 12 VHF Receiver Cert. Basis - TC 2A13	_____	3.4	58.6	199
219	Narco Nav 14 VHF Receiver Cert. Basis - TC 2A13	_____	2.5	57.4	144
221	Narco Nav 111 Cert. Basis - TSO C36c, C40a, C66a	_____	2.5	58.6	147
223	Narco Nav 112 Receiver Cert. Basis - TSO C36c, C40a, C66c, C34c	_____	3.3	58.6	193
225	Narco Nav 114 VHF Receiver Cert. Basis - TSO C38b, C40a, C36c, C34c, C66a	_____	2.5	57.4	144
227	Narco UGR-2A Glide Slope Cert. Basis - TSO C34b	_____	4.2	154.0	647
229	Narco UGR-3 Glide Slope Cert. Basis - TC 2A13	_____	4.2	154.0	647
231	Narco MBT-12-R, Marker Beacon Cert. Basis - TC 2A13	_____	3.1	69.1	214
233	Narco CP-125 Audio Selector Panel Cert. Basis - TC 2A13	_____	2.2	60.2	132

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
235	Narco DME-190 Cert. Basis - TC 2A13	_____	5.9	61.0	360
237	Narco DME 195 Receiver and Indicator Cert. Basis - TSO C66a	_____	*13.2	**154.5	2039
239	Narco ADF-140 a. Single	_____	6.0	91.2	547
	b. Dual	_____	17.9	107.6	1926
	Cert. Basis - TSO C41c				
241	Narco AT50A Transponder Cert. Basis - TSO C74b	_____	*3.0	57.3	172
	a. Narco AR-500 Altitude Encoder				
	Cert. Basis - TSO C88	_____	1.0	51.5	52

*Weight includes antenna and cable.

**This arm and moment is applicable only when installed with Collins avionics.

THIS PAGE INTENTIONALLY LEFT BLANK

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
243	Antenna and Cable	<u>X</u>			
	a. Nav Receiving	<u> </u>	1.6	171.3	274
	b. #1 VHF Comm	<u> </u>	0.7	125.7	88
	c. #2 VHF Comm	<u> </u>	0.8	147.5	118
	d. Glide Slope	<u> </u>	0.9	120.0	108
	e. Single ADF Sense	<u> </u>	0.4	150.0	60
	Cert. Basis - TC 2A13				
245	Anti Static Antenna and Cable				
	a. #1 VHF Comm	<u>X</u>	1.4	144.3	202
	b. #2 VHF Comm	<u> </u>	1.5	170.7	256
	c. Single ADF Sense	<u> </u>	0.5	147.5	74
	Cert. Basis - TC 2A13				
247	Emergency Locator Transmitter	<u>X</u>			
	a. Antenna and Coax	<u>X</u>	1.7	236.2	402
	b. Shelf and Access Hole	<u>X</u>	0.2	224.4	45
	Cert. Basis - TC 2A13		0.3	235.4	71
249	Microphone				
	a. Piper Dwg. 68856-10	<u> </u>	0.3	69.9	21
	b. Piper Dwg. 68856-11	<u> </u>	0.6	69.9	42
	c. Piper Dwg. 68856-12	<u>X</u>	0.3	69.9	21
	Cert. Basis - TC 2A13				
251	Cabin Speaker	<u>X</u>			
	Cert. Basis - TC 2A13	<u> </u>	0.8	99.0	79
253	Headset, Piper Dwg. 68856-10	<u>X</u>			
	Cert. Basis - TC 2A13	<u> </u>	0.5	60.0	30

*Weight and moment difference between standard and optional equipment.

SECTION 6
WEIGHT AND BALANCE

PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR

(m) Radio Equipment
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
-------------	------	-------------------	--------------------	------------------------	--------------------

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

(n) Miscellaneous
(Optional Equipment)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
263	Zinc Chromate Finish Cert. Basis - TC 2A13	_____	5.0	158.0	790
265	Stainless Steel Control Cables Cert. Basis - TC 2A13	_____	—	—	—
267	Overhead Vent System Piper Dwg. 76304-9 Cert. Basis - TC 2A13	_____	6.4	159.6	1022
269	Overhead Vent System with Ground Ventilating Blower Piper Dwg. 76304-10 Cert. Basis - TC 2A13	X _____	14.0	170.7	2390
271	Rear Seat Vents Cert. Basis - TC 2A13	X _____	2.5	98.0	245
273	Assist Step, Piper Dwg. 65384 Cert. Basis - TC 2A13	X _____	1.8	156.0	281
275	Super Cabin Sound Proofing, Piper Dwg. 79030-2 Cert. Basis - TC 2A13	X _____	18.1	86.8	1571
277	Adjustable Front Seat (Left). Piper Dwg. 79591-0 Cert. Basis - TC 2A13	X _____	*6.6	80.3	530
279	Adjustable Front Seat (Right). Piper Dwg. 79591-1 Cert. Basis - TC 2A13	_____	*6.6	79.6	525

*Weight and moment difference between standard and optional equipment.

SECTION 6
WEIGHT AND BALANCE

PIPER AIRCRAFT CORPORATION
PA-28-151, CHEROKEE WARRIOR

(n) Miscellaneous
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
281	Headrests (2) Front. Piper Dwg. 79337-18. Cert. Basis - TC 2A13	X _____	2.2	94.5	208
283	Inertia Safety Belts (Rear) (2) 0.8 lbs. each, Piper PS50039-4-14 Cert. Basis - TC 2A13	_____	1.6	140.3	224
285	Sun Visors Piper Dwg. 66991-0 Cert. Basis - TC 2A13	X _____	1.5	85.0	128
287	Assist Strap, Piper Dwg. 79455 Cert. Basis - TC 2A13	X _____	0.2	109.5	22
289	Delux Carpeting Cert. Basis - TC 2A13	X _____	*2.6	97.8	254
291	Fire Extinguisher. Piper Dwg. 76167-2 Cert. Basis - TC 2A13	_____	4.6	71.0	327
293	Tow Bar Piper Dwg. 99458 Cert. Basis - TC 2A13	X _____	1.3	140.0	182

*Weight and moment difference between standard and optional equipment.

(n) Miscellaneous
(Optional Equipment) (cont)

Item No.	Item	Mark if Instl.	Weight (Pounds)	Arm (In.) Aft Datum	Moment (Lb-In.)
-------------	------	-------------------	--------------------	------------------------	--------------------

TOTAL OPTIONAL EQUIPMENT

119.1

107.9

12851

EXTERIOR FINISH

Base Color Juneau White

Registration No. Color Black

Trim Color Madrid Red

Type Finish Lacquer

Accent Color Dakota Black

ISSUED: JUNE 17, 1976

REPORT: VB-780
6-55

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 7

DESCRIPTION AND OPERATION OF THE AIRPLANE AND ITS SYSTEMS

Paragraph No.		Page No.
7.1	The Airplane	7-1
7.3	Airframe	7-1
7.5	Engine and Propeller	7-3
7.7	Landing Gear	7-5
7.9	Flight Controls	7-7
7.11	Engine Controls	7-8
7.13	Fuel System	7-10
7.15	Electrical System	7-12
7.17	Vacuum System	7-15
7.19	Instrument Panel	7-16
7.21	Pitot-Static System	7-18
7.23	Heating and Ventilating System	7-21
7.25	Cabin Features	7-21
7.27	Baggage Area	7-22
7.29	Stall Warning	7-22
7.31	Finish	7-22
7.33	Piper External Power	7-23
7.35	Emergency Locator Transmitter	7-23

SECTION 7

DESCRIPTION AND OPERATION OF THE AIRPLANE AND ITS SYSTEMS

7.1 THE AIRPLANE

The Cherokee Warrior is a single-engine, fixed gear monoplane of all metal construction with low semi-tapered wings. It has four place seating and a two hundred pound baggage capacity.

7.3 AIRFRAME

The primary structure, with the exception of the steel tube engine mount, steel landing gear struts and isolated areas, is of aluminum alloy construction. Fiberglass and thermoplastic are used extensively in the extremities - the wing tips, the engine cowling, etc. - and in nonstructural components throughout the airplane.

The fuselage is a conventional semi-monocoque structure. On the right side of the airplane is a cabin door for entrance and exit and a baggage door to provide loading into the 24 cubic foot compartment.

The wing is a conventional semi-tapered design incorporating a laminar flow, NACA 65₂415, airfoil section. The cantilever wings are attached to each side of the fuselage by insertion of the butt ends of the main spars into a spar box carry-through which is an integral part of the fuselage structure. The spar box carry-through structure, located under the rear seat, provides in effect a continuous main spar with splices at each side of the fuselage. There are also fore and aft attachments at the rear and at an auxiliary front spar.

THIS PAGE INTENTIONALLY LEFT BLANK

7.5 ENGINE AND PROPELLER

The PA-28-151 is powered by a Lycoming O-320-E3D four cylinder, direct drive, horizontally opposed engine rated at 150 HP at 2700 RPM. It is equipped with a starter, a 60 amp 14 volt alternator, a shielded ignition, dual magnetos, vacuum pump drive, a fuel pump, and a wetted polyurethane foam induction air filter.

The engine compartment is accessible for inspection through top-hinged side panels on either side of the engine cowlings. The engine cowlings are cantilever structures attached at the fire wall. The engine mounts are constructed of steel tubing, and dynafocal mounts are provided to reduce vibration.


The exhaust system is constructed of stainless steel and incorporates a single muffler with heater shrouds to supply heated air for the cabin, the defroster system and the carburetor deicing system.

An oil cooler is located on the left rear of the engine mounted to the engine baffling. Engine cooling air, which is picked up in the nose section of the engine cowling and carried through the baffling, is utilized on the left side for the oil cooler. A winterization plate is provided to restrict air during winter operation (refer to paragraph 8.29).

Engine air enters on either side of the propeller through openings in a nose cowling and is carried through the engine baffling around the engine and oil cooler. Air for the muffler shroud is also picked up from the nose cowling and carried through a duct to the shroud. Carburetor induction air enters a chin scoop on the lower right cowling and is passed through a wetted polyurethane filter to the carburetor air box. Heated air enters the carburetor air box through a hose connected to the heater shroud.

A McCauley 1C160/EGM7653 or a Sensenich 74DM6-0-58 fixed pitch propeller is installed as standard equipment. The McCauley propeller has a diameter of 76 inches with a pitch of 53 inches and the Sensenich has a 74 inch diameter with a 58 inch pitch. The pitch of both propellers is determined at 75% of the diameter. Both propeller units are of an aluminum alloy construction.

The pilot should read and follow the procedures recommended in the Lycoming Operator's Manual for this engine in order to obtain maximum engine efficiency and time between engine overhauls.



MAIN WHEEL ASSEMBLY

Figure 7-1

7.7 LANDING GEAR


The fixed gear PA-28-151 is equipped with a Cleveland 5.00 x 5 wheel on the nose gear and a Cleveland 6.00 x 6 wheel on each main gear (Figure 7-1). Cleveland single disc hydraulic brake assemblies are provided on the main gear. The nose gear has a 5.00 x 5 four ply tire, while the main wheel assemblies have 6.00 x 6 four ply tires. At gross weight, the main gear tires require a pressure of 24 psi, and the nose gear tire requires a pressure of 30 psi.

The nose gear is steerable through a 30 degree arc each side of center by the use of the rudder pedals and toe brakes. A spring device is incorporated for rudder centering and to provide rudder trim. A bungee assembly on the nose gear steering mechanism reduces ground steering effort and dampens shocks and bumps during taxiing. The steering mechanism also incorporates a shimmy dampener.

The three struts are of the air-oil type with the normal static load extension being 3.25 inches for the nose gear and 4.50 inches for the main gear.

The brakes are actuated by toe brake pedals which are attached to the rudder pedals or by a hand lever and master cylinder located below and behind the center of the instrument sub panel. Hydraulic cylinders are located above each pedal and adjacent to the hand brake lever. The brake fluid reservoir is installed on the top left front face of the fire wall. The parking brake is incorporated in the master cylinder and is actuated by pulling back on the brake lever and depressing the knob attached to the left side of the handle. To release the parking brake, pull back on the brake lever to disengage the catch mechanism and allow the handle to swing forward (refer to Figure 7-5).

THIS PAGE INTENTIONALLY LEFT BLANK



FLIGHT CONTROL CONSOLE

Figure 7-3

7.9 FLIGHT CONTROLS

Dual flight controls are provided on the Warrior as standard equipment. The flight controls actuate the control surfaces through a cable system.

The horizontal surface (stabilator) is of the flying tail design with a trim tab mounted on the trailing edge. This tab serves the dual function of providing trim control and pitch control forces. The trim tab is actuated by a trim control wheel located on the control console between the front seats (Figure 7-3). Forward rotation of the wheel gives nose down trim and aft rotation gives nose up trim.

The rudder is conventional in design and incorporates a rudder trim. The trim mechanism is a spring loaded recentering device. The trim control is located on the right side of the pedestal below the throttle quadrant (refer to Figure 7-5). Turning the trim control clockwise gives nose right trim and counterclockwise rotation gives nose left trim.

Manually controlled flaps are provided on the PA-28-151. The flaps are balanced and spring loaded to return to the retracted (up) position. A control handle, which is located between the two front seats on the control console (Figure 7-3), extends the flaps by the use of a control cable. To extend the flaps, the handle is pulled up to the desired flap setting of 10, 25 or 40 degrees. To retract, depress the button on the end of the handle and lower the control. When extending or retracting flaps, there is a pitch change in the airplane. This pitch change can be corrected either by stabilator trim or increased control wheel force. When the flaps are in the retracted (up) position the right flap, provided with an over-center lock mechanism, acts as a step.

NOTE

The right flap will support a load only in the fully retracted (up) position. When the flap is to be used as a step, make sure the flaps are in the retracted (up) position.


7.11 ENGINE CONTROLS

Engine controls consist of a throttle control and a mixture control lever. These controls are located on the control quadrant on the lower center of the instrument panel (Figure 7-5) where they are accessible to both the pilot and the copilot. The controls utilize teflon-lined control cables to reduce friction and binding.

The throttle lever is used to adjust engine RPM. The mixture control lever is used to adjust the air to fuel ratio. The engine is shut down by the placing of the mixture lever in the full lean position. In addition, the mixture control has a lock to prevent inadvertent activation of the mixture control. For information on the leaning procedure, see the Avco-Lycoming Operator's Manual.


The friction adjustment lever on the right side of the control quadrant may be adjusted to increase or decrease the friction holding the throttle and mixture controls or to lock the controls in a selected position.

The carburetor heat control lever is located to the right of the control quadrant on the instrument panel. The control is placarded with two positions: "ON" (down), "OFF" (up).



CONTROL QUADRANT AND CONSOLE

Figure 7-5



FUEL SELECTOR

Figure 7-7

7.13 FUEL SYSTEM


Fuel is stored in two twenty-five gallon (24 gallons usable) fuel tanks, giving the airplane a total capacity of fifty U.S. gallons (48 gallons usable). The tanks are secured to the leading edge of each wing with screws and nut plates. This allows removal for service or inspection.

The fuel tank selector control (Figure 7-7) is located on the left side panel forward of the pilot's seat. The button on the selector cover must be depressed and held while the handle is moved to the OFF position. The button releases automatically when the handle is moved back to the ON position.

An auxiliary electric fuel pump is provided in case of the failure of the engine driven pump. The electric pump should be ON for all takeoffs and landings and when switching tanks. The fuel pump switch is located in the switch panel above the throttle quadrant.

The fuel drains should be opened daily prior to first flight to check for water or sediment. Each tank has an individual drain at the bottom, inboard rear corner.

A fuel strainer, located on the lower left front of the fire wall, has a drain which is accessible from outside the nose section. The strainer should also be drained before the first flight of the day. Refer to paragraph 8.21 for the complete fuel draining procedure.



FUEL SYSTEM SCHEMATIC

Figure 7-9

Fuel quantity and fuel pressure gauges are mounted in a gauge cluster located on the left side of the instrument panel to the right of the control wheel (refer to Figure 7-15).

An optional engine priming system is available to facilitate starting. The primer pump is located to the immediate left of the throttle quadrant (refer to Figure 7-5).

7.15 ELECTRICAL SYSTEM

The electrical system includes a 14 volt 60 ampere alternator, voltage regulator, overvoltage relay, battery contactor and a standard 12 volt 25 ampere hour or an optional 12 volt 35 ampere hour battery (Figure 7-11). The battery is mounted in a thermoplastic box located immediately aft of the main spar on the right side of the fuselage below the rear passenger seat. The voltage regulator and overvoltage relay are located on the forward left side of the fuselage behind the instrument panel.

Electrical switches are located on the right center instrument panel, and the circuit breakers are located on the lower right instrument panel. A rheostat switch on the left side of the switch panel controls the optional navigation lights and the radio lights. A similar switch on the right side of the switch panel controls and dims the optional panel lights. The master switch, anti-collision light, landing light and fuel pump are also located on the switch panel and are controlled by rocker type switches. Each circuit breaker on the panel is of the push to reset type and is clearly marked as to its function and amperage. Circuit provisions have been included to handle the addition of communication and navigational equipment (refer to Figure 7-13).

WARNING

Anti-collision lights should not be operated when flying through clouds, fog or haze, since reflected light can produce spatial disorientation. Strobe lights should not be used in close proximity to the ground, such as during taxiing, takeoff or landing.

Standard electrical accessories include a starter, an electric fuel pump, an audible stall warning indicator, fuel gauges, ammeter, and annunciator panel.


The annunciator panel includes alternator and low oil pressure indicator lights. When the optional gyro system is installed, the annunciator panel also includes a low vacuum indicator light. The annunciator panel lights are provided only as a warning to the pilot that a system may not be operating properly, and that he should check and monitor the applicable system gauge to determine when or if any necessary action is required.

The system also provides for such optional electrical accessories as additional lights and gauges, a heated pitot head, and communication and navigational equipment.

The master switch is a split rocker switch. One side of the switch is the battery side ("BAT") and the other is the alternator side ("ALT"). Henceforth, the words "master switch" used in this manual will mean both "BAT" and "ALT" switches and they are to be depressed simultaneously to OFF or ON as directed.


Unlike previous generator systems, the ammeter as installed does not show battery discharge: rather, it indicates the electrical load on the alternator in amperes. With all the electrical equipment off and the master switch on, the ammeter will indicate the charging rate of the battery. As each electrical unit is switches on, the ammeter will indicate the total ampere draw of all the units including the battery. For example, the maximum continuous load for night flight with radios on is about 30 amperes. This 30 ampere value plus approximately 2 amperes for a fully charged battery will appear continuously under these flight conditions. The amount of current shown on the ammeter will tell immediately if the alternator system is operating normally, as the amount of current shown should equal the total amperage drawn by the electrical equipment which is operating.

The overvoltage relay protects the electronics equipment from a momentary overvoltage condition (approximately 16.5 volts and up), or a catastrophic regulator failure. If no output is indicated on the ammeter during flight, reduce the electrical load by turning off all unnecessary electrical equipment. Check both the 5 ampere field breaker and the 60 ampere output breaker and reset if open. If neither circuit breaker is open, turn the "ALT" switch off for 1 second to reset the overvoltage relay. If the ammeter continues to indicate no output, maintain minimum electrical load and terminate the flight as soon as practical.



ALTERNATOR AND STARTER SCHEMATIC

Figure 7-11



CIRCUIT BREAKER PANEL

Figure 7-13

7.17 VACUUM SYSTEM*

The vacuum system is designed to operate the air driven gyro instruments. This includes the directional and attitude gyros when installed. The system consists of an engine driven vacuum pump, a vacuum regulator, a filter and the necessary plumbing.

The vacuum pump is a dry type pump. A shear drive protects the pump from damage. If the drive shears, the gyros will become inoperative.

A vacuum gauge, mounted on the far right instrument panel provides a pilot check for the system during operation. A decrease in pressure in a system that remained constant over an extended period may indicate a dirty filter, dirty screens, possibly a sticky vacuum regulator or leak in the system (a low vacuum indicator light is provided in the annunciator panel). Zero pressure would indicate a sheared pump drive, defective pump, possibly a defective gauge or collapsed line. In the event of any gauge variation from the norm, the pilot should have a mechanic check the system to prevent possible damage to the system components or eventual failure of the system.

A vacuum regulator is provided in the system to protect the gyros. The valve is set so the normal vacuum reads $5.0 \pm .1$ inches of mercury, a setting which provides sufficient vacuum to operate all the gyros at their rated RPM. Higher settings will damage the gyros and with a low setting the gyros will be unreliable. The regulator is located behind the instrument panel. Vacuum pressure, even though set correctly, can read lower at very high altitude (above 12,000 ft). and at low engine RPM (usually on approach or during training maneuvers. This is normal and should not be considered a malfunction.

*Optional equipment


7.19 INSTRUMENT PANEL

The instrument panel (Figure 7-15) is designed to accommodate instruments and avionics equipment for VFR and IFR flights.

The radios and the circuit breakers are located on the upper and lower right panel respectively, and have circuits provided for the addition of optional radio equipment. An engine cluster is located to the right of the pilot control wheel and includes a fuel pressure gauge, a right and left main fuel quantity gauge, an oil temperature gauge and an oil pressure gauge.

Standard instruments on the Warrior panel include a compass, an airspeed indicator, a tachometer, an altimeter, an ammeter, an engine cluster, and an annunciator panel. The compass is mounted on the windshield bow in clear view of the pilot. The annunciator panel is mounted in the upper instrument panel to warn the pilot of a possible malfunction in the alternator, oil pressure, or vacuum systems.

Instrument options available for the panel includes a suction gauge, vertical speed indicator, attitude gyro, directional gyro, clock, tru-speed indicator and a turn and slip indicator or turn coordinator. The attitude gyro and directional gyro are vacuum operated through the use of a vacuum pump installed on the engine, while the turn and slip indicator is electrically operated. The vacuum suction gauge is on the far right of the instrument panel.



INSTRUMENT PANEL

Figure 7-15

7.21 PITOT-STATIC SYSTEM

The system supplies both pitot and static pressure for the airspeed indicator, altimeter, and the optional vertical speed indicator (Figure 7-17).

Pitot and static pressure are picked up by a pitot head installed on the bottom of the left wing and carried through pitot and static lines within the wing and fuselage to the gauges on the instrument panel.

A static valve, which is mounted to the knee guard below the instrument panel on the left side, provides an alternate static source for the system when opened.


Both the pitot and static lines can be drained through separate drain valves located on the left lower side of the fuselage interior.

A heated pitot head, which alleviates problems with icing and heavy rain, is available as optional equipment. The switch for the heated pitot head is located on the electrical switch panel to the left of the right control wheel.

To prevent bugs and water from entering the pitot and static pressure holes, a cover should be placed over the pitot head. A partially or completely blocked pitot head will give erratic or zero readings on the instruments.


NOTE

During the preflight, check to make sure the pitot cover is removed.



PITOT-STATIC SYSTEM

Figure 7-17



HEATING AND VENTILATING SYSTEM

Figure 7-19

7.23 HEATING AND VENTILATING SYSTEM

Heat for the cabin interior and the defroster system is provided by a shroud attached to the muffler (Figure 7-19). The amount of heat can be regulated with the controls located on the far right side of the instrument panel.

The airflow between front and rear seats can be regulated by the heat diversion controls located on either side of the console atop the heat ducts.

CAUTION

When cabin heat is operated, heat duct surface becomes hot. This could result in burns if arms or legs are placed too close to heat duct outlets or surface.

Fresh air inlets are located in the leading edges of the wings near the fuselage. At each front seat location there is an adjustable fresh air outlet on the side of the cabin near the floor. Rear seat vents are optional. Cabin air is exhausted through an outlet located below the rear seat.

An optional overhead ventilating system with outlets over each seat is also available. An additional option to aid in fresh air circulation is a cabin air blower to force air through the overhead vent system. This blower is operated by a fan switch with four positions - "OFF," "LOW," "MED," and "HIGH." The switch is located on the right side of the instrument panel with the heater and defroster controls.

7.25 CABIN FEATURES

For ease of entry and exit and for pilot-passenger comfort, the front seats are adjustable fore and aft. The right front seat tilts forward to allow easy entry to the rear seats. The cabin interior includes a pilot storm window, ash trays and armrests on each front seat, two map pockets and pockets on the backs of the front seats.

The front seats can be equipped with optional headrests and optional vertical adjustment.

Seat belts are standard equipment for both front and rear seats. The shoulder straps controlled by inertia reels are standard equipment on the front seats and are offered as an option for the rear seats. The shoulder strap is routed over the shoulder adjacent to the window and attached to the seat belt in the general area of the occupants' inboard hip.

A check of the inertia reel mechanism is made by pulling sharply on the strap. The reel should lock in place under this test and prevent the strap from extending. For normal body movements, the strap will extend or retract as required.

7.27 BAGGAGE AREA

A 24 cubic foot baggage area, located behind the rear seat, is accessible from the cabin or loaded through a large 20 x 22 inch outside baggage door on the right side of the fuselage. Maximum capacity is 200 pounds. Tie-down straps are available and they should be used at all times.

NOTE

It is the pilot's responsibility to be sure when the baggage is loaded that the aircraft C.G. falls within the allowable C.G. range. (See Weight and Balance Section.)

7.29 STALL WARNING

An approaching stall is indicated by an audible alarm located behind the instrument panel. The indicator activates at between five and ten knots above stall speed.

7.31 FINISH

All exterior surfaces are primed with etching primer and finished with acrylic lacquer available in a variety of colors and combinations. An optional polyurethane enamel finish is available.

7.33 PIPER EXTERNAL POWER*

An optional starting installation known as Piper External Power (PEP) is accessible through a receptacle located on the right side of the fuselage aft of the baggage door. An external battery can be connected to the socket, thus allowing the operator to crank the engine without having to gain access to the airplane's battery. Instructions on a placard located on the cover of the receptacle should be followed before using the external power. For instructions on the use of the PEP see; STARTING WITH EXTERNAL POWER SOURCE in Section 4 - Normal Operating Procedures.

7.35 EMERGENCY LOCATOR TRANSMITTER*

The Emergency Locator Transmitter (ELT) when installed, is located in the aft portion of the fuselage just below the stabilator leading edge and is accessible through a plate on the right side of the fuselage. This plate is attached with three slotted-head nylon screws for ease of removal; these screws may be readily removed with a variety of common items such as a dime, a key, a knife blade, etc. If there are no tools available in an emergency the screw heads may be broken off by any means. The ELT is an emergency locator transmitter which meets the requirements of FAR 91.52. It is automatically activated by a longitudinal force of 5 g's and transmits a distress signal on both 121.5 MHz and 243.0 MHz for a period of from 48 hours in low temperature areas up to 100 hours in high temperature areas. The unit operates on a self-contained battery.

The battery has a useful life of 10 years. However, to comply with FAA regulations it must be replaced after 5 years of shelf life or service life. The battery should also be replaced if the transmitter has been used in an emergency situation or if accumulated test time exceeds one hour. The replacement date is marked on the transmitter label.

On the unit itself is a three position selector switch placarded "OFF," "ARM" and "ON." The "ARM" position is provided to set the unit to the automatic position so that it will transmit only after impact and will continue to transmit until the battery is drained to depletion or until the switch is manually moved to the "OFF" position. The "ARM" position is selected when the transmitter is installed at the factory and the switch should remain in that position whenever the unit is installed in the airplane. The "ON" position is provided so the unit can be used as a portable transmitter or in the event the automatic feature was not triggered by impact or to periodically test the function of the transmitter.

Select the "OFF" position when changing the battery, when rearming the unit if it has been activated for any reason, or to discontinue transmission.

NOTE

If the switch has been placed in the "ON" position for any reason, the "OFF" position has to be selected before selecting "ARM." If "ARM" is selected directly from the "ON" position, the unit will continue to transmit in the "ARM" position.

*Optional equipment

A pilot's remote switch, located on the left side panel, is provided to allow the transmitter to be controlled from inside the cabin. The pilot's remote switch is placarded "ON, AUTO/ARM and OFF/RESET." The switch is normally left in the "AUTO/ARM" position. To turn the transmitter off, move the switch momentarily to the "OFF/RESET" position. The aircraft master switch must be "ON" to turn the transmitter "OFF." To actuate the transmitter for tests or other reasons, move the switch upward to the "ON" position and leave it in that position as long as transmission is desired.

The unit is equipped with a portable antenna to allow the locator to be removed from the airplane in case of an emergency and used as a portable signal transmitter.

The locator should be checked during the ground check to make certain the unit has not been accidentally activated. Check by tuning a radio receiver to 121.5 MHz. If there is an oscillating sound, the locator may have been activated and should be turned off immediately. Reset to the "ARM" position and check again to insure against outside interference.

NOTE

If for any reason a test transmission is necessary, the test transmission should be conducted only in the first five minutes of any hour and limited to three audio sweeps. If tests must be made at any other time, the tests should be coordinated with the nearest FAA tower or flight service station.

TABLE OF CONTENTS

SECTION 8

AIRPLANE HANDLING, SERVICING AND MAINTENANCE

Paragraph No.		Page No.
8.1	General	8-1
8.3	Airplane Inspection Periods	8-3
8.5	Preventive Maintenance	8-4
8.7	Airplane Alterations	8-5
8.9	Ground Handling	8-6
8.11	Engine Air Filter	8-8
8.13	Brake Service	8-8
8.15	Landing Gear Service	8-10
8.17	Propeller Service	8-11
8.19	Oil Requirements	8-11
8.21	Fuel System	8-11
8.23	Tire Inflation	8-13
8.25	Battery Service	8-14
8.27	Cleaning	8-14
8.29	Winterization	8-16

SECTION 8

AIRPLANE HANDLING, SERVICING AND MAINTENANCE

8.1 GENERAL

This section provides guidelines relating to the handling, servicing, and maintenance of the Warrior. For complete maintenance instructions, refer to the PA-28-151 Maintenance Manual.

Every owner should stay in close contact with an authorized Piper Service Center or Piper's Customer Services Department to obtain the latest information pertaining to their airplane, and to avail themselves of Piper Aircraft's support systems.

Piper Aircraft Corporation takes a continuing interest in having owners get the most efficient use from their aircraft and keeping it in the best mechanical condition. Consequently, Piper Aircraft, from time to time, issues service releases including Service Bulletins, Service Letters, Service Spares Letters, and others relating to the airplane.

Service Bulletins are of special importance and Piper considers compliance mandatory. These are sent directly to the latest FAA-registered owners in the United States (U.S.) and Piper Service Centers worldwide. Depending on the nature of the release, material and labor allowances may apply. This information is provided to all authorized Service Centers.

Service Letters deal with product improvements and servicing techniques pertaining to the airplane. They are sent to Piper Service Centers and, if necessary, to the latest FAA-registered owners in the U.S. Owners should give careful attention to Service Letter information.

Service Spares Letters offer improved parts, kits, and optional equipment which were not available originally, and which may be of interest to the owner.

Piper Aircraft Corporation offers a subscription service for Service Bulletins, Service Letters, and Service Spares Letters. This service is available to interested persons, such as owners, pilots, and mechanics at a nominal fee, and may be obtained through an authorized Piper Service Center or Piper's Customer Services Department.

Maintenance manuals, parts catalogs, and revisions to both, are available from Piper Service Centers or Piper's Customer Services Department.

Any correspondence regarding the airplane should include the airplane model and serial number to ensure proper response.

THIS PAGE INTENTIONALLY LEFT BLANK

8.3 AIRPLANE INSPECTION PERIODS

Piper Aircraft Corporation has developed inspection times and required inspection intervals (i.e.: 50, 100, 500, and 1000 hours) for the specific model aircraft. Appropriate forms are contained in the applicable Piper Service/Maintenance Manual, and should be complied with by a properly trained, knowledgeable, and qualified mechanic at a Piper Authorized Service Center or a reputable repair shop. Piper Aircraft Corporation cannot accept responsibility for the continued airworthiness of any aircraft not maintained to these standards, and/or not brought into compliance with applicable Service Bulletins issued by Piper Aircraft Corporation, instructions issued by the engine, propeller, or accessory manufacturers or Airworthiness Directives issued by the FAA.

A programmed inspection, approved by the Federal Aviation Administration (FAA), is also available to the owner. This involves routine and detailed inspections to allow maximum utilization of the airplane. Maintenance inspection costs are reduced, and the maximum standard of continued airworthiness is maintained. Complete details are available from Piper Aircraft Corporation.

In addition, but in conjunction with the above, the FAA requires periodic inspections on all aircraft to keep the Airworthiness Certificate in effect. The owner is responsible for assuring compliance with these inspection requirements and for maintaining proper documentation in logbooks and/or maintenance records.

A spectographic analysis of the engine oil is available from several sources. This inspection, if performed properly, provides a good check of the internal condition of the engine. To be accurate, induction air filters must be cleaned or changed regularly, and oil samples must be taken and sent in at regular intervals.

8.5 PREVENTIVE MAINTENANCE

The holder of a Pilot Certificate issued under FAR Part 61 may perform certain preventive maintenance described in FAR Part 43. This maintenance may be performed only on an aircraft which the pilot owns or operates and which is not used to carry persons or property for hire, except as provided in applicable FAR's. Although such maintenance is allowed by law, each individual should make a self-analysis as to whether he has the ability to perform the work.

All other maintenance required on the airplane should be accomplished by appropriately licensed personnel.

If maintenance is accomplished, an entry must be made in the appropriate logbook. The entry should contain:

- (a) The date the work was accomplished.
- (b) Description of the work.
- (c) Number of hours on the aircraft.
- (d) The certificate number of pilot performing the work.
- (e) Signature of the individual doing the work.

8.7 AIRPLANE ALTERATIONS

If the owner desires to have his aircraft modified, he must obtain FAA approval for the alteration. Major alterations accomplished in accordance with Advisory Circular 43.13-2, when performed by an A & P mechanic, may be approved by the local FAA office. Major alterations to the basic airframe or systems not covered by AC 43.13-2 require a Supplemental Type Certificate.

The owner or pilot is required to ascertain that the following Aircraft Papers are in order and in the aircraft.

- (a) To be displayed in the aircraft at all times:
 - (1) Aircraft Airworthiness Certificate Form FAA-8100-2.
 - (2) Aircraft Registration Certificate Form FAA-8050-3.
 - (3) Aircraft Radio Station License if transmitters are installed.
- (b) To be carried in the aircraft at all times:
 - (1) Pilot's Operating Handbook.
 - (2) Weight and Balance data plus a copy of the latest Repair and Alteration Form FAA-337, if applicable.
 - (3) Aircraft equipment list.

Although the aircraft and engine logbooks are not required to be in the aircraft, they should be made available upon request. Logbooks should be complete and up to date. Good records will reduce maintenance cost by giving the mechanic information about what has or has not been accomplished.

8.9 GROUND HANDLING

(a) Towing

The airplane may be moved on the ground by the use of the nose wheel steering bar that is stowed below the forward ledge of the baggage compartment or by power equipment that will not damage or excessively strain the nose gear steering assembly. Towing lugs are incorporated as part of the nose gear fork.

CAUTION

When towing with power equipment, do not turn the nose gear beyond its steering radius in either direction, as this will result in damage to the nose gear and steering mechanism.

CAUTION

Do not tow the airplane when the controls are secured.

In the event towing lines are necessary, ropes should be attached to both main gear struts as high up on the tubes as possible. Lines should be long enough to clear the nose and/or tail by not less than fifteen feet, and a qualified person should ride in the pilot's seat to maintain control by use of the brakes.

(b) Taxiing

Before attempting to taxi the airplane, ground personnel should be instructed and approved by a qualified person authorized by the owner. Engine starting and shut-down procedures as well as taxi techniques should be covered. When it is ascertained that the propeller back blast and taxi areas are clear, power should be applied to start the taxi roll, and the following checks should be performed:

- (1) Taxi a few feet forward and apply the brakes to determine their effectiveness.
- (2) While taxiing, make slight turns to ascertain the effectiveness of the steering.
- (3) Observe wing clearance when taxiing near buildings or other stationary objects. If possible, station an observer outside the airplane.
- (4) When taxiing over uneven ground, avoid holes and ruts.
- (5) Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel, or any loose material that may cause damage to the propeller blades.

(c) Parking

When parking the airplane, be sure that it is sufficiently protected from adverse weather conditions and that it presents no danger to other aircraft. When parking the airplane for any length of time or overnight, it is suggested that it be moored securely.

- (1) To park the airplane, head it into the wind if possible.
- (2) Set the parking brake by pulling back on the brake lever and depressing the knob on the handle. To release the parking brake, pull back on the handle until the catch disengages; then allow the handle to swing forward.

CAUTION

Care should be taken when setting brakes that are overheated or during cold weather when accumulated moisture may freeze a brake.

- (3) Aileron and stabilator controls should be secured with the front seat belt and chocks used to properly block the wheels.

(d) Mooring

The airplane should be moored for immovability, security and protection. The following procedures should be used for the proper mooring of the airplane:

- (1) Head the airplane into the wind if possible.
- (2) Retract the flaps.
- (3) Immobilize the ailerons and stabilator by looping the seat belt through the control wheel and pulling it snug.
- (4) Block the wheels.
- (5) Secure tie-down ropes to the wing tie-down rings and to the tail skid at approximately 45 degree angles to the ground. When using rope of non-synthetic material, leave sufficient slack to avoid damage to the airplane should the ropes contract.

CAUTION

Use bowline knots, square knots or locked slip knots. Do not use plain slip knots.

NOTE

Additional preparations for high winds include using tie-down ropes from the landing gear forks and securing the rudder.

- (6) Install a pitot head cover if available. Be sure to remove the pitot head cover before flight.
- (7) Cabin and baggage doors should be locked when the airplane is unattended.

8.11 ENGINE AIR FILTER

The wet-type polyurethane foam air filter must be inspected at least once every fifty hours. Under extremely adverse operating conditions, it may be necessary to inspect the filter more frequently. The filter is disposable and inexpensive and a spare should be kept on hand for a rapid replacement.

(a) Removal Of Engine Air Filter

The filter is located in the lower right front of the engine compartment and may be removed by the following procedure:

- (1) Open the right side of the engine cowling.
- (2) Loosen each of the four quarter-turn fasteners securing the air filter cover.
- (3) Separate the cover and remove the filter.
- (4) Inspect the filter. If it is excessively dirty or shows any damage, replace it immediately.


(b) Installation Of Engine Air Filter

When replacing the filter, install the filter in the reverse order of removal.

8.13 BRAKE SERVICE

The brake system is filled with MIL-H-5606 (petroleum base) hydraulic brake fluid. The fluid level should be checked periodically or at every 50 hour inspection and replenished when necessary. The brake reservoir is located on the fire wall in the engine compartment. If the entire system must be refilled, fill with fluid under pressure from the brake end of the system. This will eliminate air from the system.

No adjustment of the brake clearances is necessary. If after extended service brake blocks become excessively worn, they should be replaced with new segments.



BRAKE SYSTEM

Figure 8-1

8.15 LANDING GEAR SERVICE

The main landing gears use Cleveland Aircraft Products 6.00 x 6 wheels and the nose gear carries a Cleveland 5.00 x 5 wheel. All three tires are four-ply rating, type III tires with tubes. (Refer to paragraph 8.23.)

Wheels are removed by taking off the hub cap, cotter pin, axle nut, and the two bolts holding the brake segment in place. Mark tire and wheel for reinstallation; then dismount by deflating the tire, removing the three through-bolts from the wheel and separating the wheel halves.

Landing gear oleos on the Cherokee Warrior should be serviced according to the instructions on the units. The main oleos should be extended under normal static load until $4.50 \pm .25$ inches of oleo piston tube is exposed, and the nose gear should show $3.25 \pm .25$ inches. Should the strut exposure be below that required, it should be determined whether air or oil is required by first raising the airplane on jacks. Depress the valve core to allow air to escape from the strut housing chamber. Remove the filler plug and slowly raise the strut to full compression. If the strut has sufficient fluid, it will be visible up to the bottom of the filler plug hole and will then require only proper inflation.

Should fluid be below the bottom of the filler plug hole, oil should be added. Replace the plug with valve core removed; attach a clear plastic hose to the valve stem of the filler plug and submerge the other end in a container of hydraulic fluid. Fully compress and extend the strut several times, thus drawing fluid from the container and expelling air from the strut chamber. To allow fluid to enter the bottom chamber of the main gear strut housing, the torque link assembly must be disconnected to let the strut be extended a minimum of 10 inches (the nose gear torque links need not be disconnected). Do not allow the strut to extend more than 12 inches. When air bubbles cease to flow through the hose, compress the strut fully and again check fluid level. Reinstall the valve core and filler plug, and the main gear torque links, if disconnected.

With fluid in the strut housing at the correct level, attach a strut pump to the air valve and with the airplane on the ground, inflate the oleo strut to the correct height.

In jacking the aircraft for landing gear or other service, two hydraulic jacks and a tail stand should be used. At least 250 pounds of ballast should be placed on the base of the tail stand before the airplane is jacked up. The hydraulic jacks should be placed under the jack points on the bottom of the wing and the airplane jacked up until the tail skid is at the right height to attach the tail stand. After the tail stand is attached and the ballast added, jacking may be continued until the airplane is at the height desired.

The steering arms from the rudder pedals to the nose wheel are adjusted at the nose wheel by turning the threaded rod end bearings in or out. Adjustment is normally accomplished at the forward end of the rods and should be done in such a way that the nose wheel is in line with the fore and aft axis of the plane when the rudder pedals and rudder are centered. Alignment of the nose wheel can be checked by pushing the airplane back and forth with the rudder centered to determine that the plane follows a perfectly straight line. The turning arc of the nose wheel is $30.0^\circ \pm 2^\circ$ in either direction and is limited by stops on the bottom of the forging.

The rudder pedal arm stops should be carefully adjusted so that the pedal arms contact the stops just after the rudder hits its stops. This guarantees that the rudder will be allowed to move through its full travel.

8.17 PROPELLER SERVICE

The spinner and backing plate should be frequently cleaned and inspected for cracks. Before each flight the propeller should be inspected for nicks, scratches, and corrosion. If found, they should be repaired as soon as possible by a rated mechanic, since a nick or scratch causes an area of increased stress which can lead to serious cracks or the loss of a propeller tip. The back face of the blades should be painted when necessary with flat black paint to retard glare. To prevent corrosion, the surface should be cleaned and waxed periodically.

8.19 OIL REQUIREMENTS

The oil capacity of the Lycoming O-320 series engine is 8 quarts, and the minimum safe quantity is 2 quarts. It is recommended that the oil be changed, and the oil filter replaced, every 50 hours or sooner under unfavorable operating conditions. Should fuel other than the specified octane rating for the power plant be used, refer to the latest issue of Lycoming Service Letter No. L185 and Lycoming Service Instruction No. 1014 for additional information and recommended service procedures. The following grades are recommended for the specified temperatures:

Average Ambient Air Temperature For Starting	Single Viscosity Grade	Multi-Viscosity Grades
Above 60° F	SAE 50	SAE 40 or SAE 50
30° to 90° F	SAE 40	SAE 40
0° to 70° F	SAE 30	SAE 40 or 20W-30
Below 10° F	SAE 20	SAE 20W-30

8.21 FUEL SYSTEM

(a) Servicing Fuel System

At every 50 hour inspection, the fuel screens in the strainer, in the electric fuel pumps, and at the carburetor inlet must be cleaned.

(b) Fuel Requirements (AVGAS ONLY)

The minimum aviation grade fuel for the PA-28-151 is 80/87. Since the use of lower grades can cause serious engine damage in a short period of time, the engine warranty is invalidated by the use of lower octanes.

Whenever 80/87 is not available, the lowest lead 100 grade should be used. (See Fuel Grade Comparison Chart, Page 8-12.) Refer to the latest issue of Lycoming Service Instruction No. 1070 for additional information.

The continuous use, more than 25% of the operating time, of the higher leaded fuels can result in increased engine deposits, both in the combustion chamber and in the engine oil. It may require increased spark plug maintenance and more frequent oil changes. The frequency of spark plug maintenance and oil drain periods will be governed by the amount of lead per gallon and the type of operation. Operation at full rich mixture requires more frequent maintenance periods; therefore it is important to use proper approved mixture leaning procedures.

Reference the latest issue of Avco Lycoming Service Letter No. L185 attached to the Engine Operators Manual for care, operation and maintenance of the airplane when using the higher leaded fuel.

A summary of the current grades as well as the previous fuel designations is shown in the following chart:

FUEL GRADE COMPARISON CHART

Previous Commercial Fuel Grades (ASTM-D910)			Current Commercial Fuel Grades (ASTM-D910-75)			Current Military Fuel Grades (MIL-G-5572E) Amendment No. 3		
Grade	Color	Max. TEL ml/U.S. gal.	Grade	Color	Max. TEL ml/U.S. gal.	Grade	Color	Max. TEL ml/U.S. gal.
80/87	red	0.5	80	red	0.5	80/87	red	0.5
91/98	blue	2.0	*100LL	blue	2.0	none	none	none
100/130	green	3.0	100	green	**3.0	100/130	green	**3.0
115/145	purple	4.6	none	none	none	115/145	purple	4.6

- * - Grade 100LL fuel in some overseas countries is currently colored green and designated as "100L."
- ** - Commercial fuel grade 100 and grade 100/130 (both of which are colored green) having TEL content of up to 4 ml/U.S. gallon are approved for use in all engines certificated for use with grade 100/130 fuel.


(d) Draining Fuel Strainer, Sumps and Lines

The fuel system sumps and strainer should be drained daily prior to the first flight and after refueling to check for water, sediment and proper fuel. Each fuel tank is equipped with an individual quick drain located at the lower inboard rear corner of the tank. The fuel strainer is equipped with a quick drain located on the front lower corner of the firewall. Each of the fuel tank sumps should be drained first, to check for water, sediment and proper fuel. Then the fuel strainer should be drained twice, once with the fuel selector valve on each tank. Each time fuel is drained, allow sufficient amount to flow and be collected in a suitable container, so that it may be examined to ensure removal of water and sediments, and for proper fuel; then discard.

CAUTION

When draining any amount of fuel, care should be taken to ensure that no fire hazard exists before starting the engine.

Each quick drain should be checked after closing it to make sure it has closed completely and is not leaking.



FUEL DRAIN

Figure 8-3

(e) Draining Fuel System

The bulk of the fuel may be drained from the system by opening the valve at the inboard end of each fuel tank. Push up on the arms of the drain valve and turn counterclockwise to hold the drain open. The remaining fuel in the system may be drained through the filter bowl. Any individual tank may be drained by closing the selector valve and then draining the desired tank.

8.23 TIRE INFLATION

For maximum service from the tires, keep them inflated to the proper pressures - 30 psi for the nose gear and 24 psi for the main gear. All wheels and tires are balanced before original installation, and the relationship of tire, tube and wheel should be maintained upon reinstallation. Unbalanced wheels can cause extreme vibration in the landing gear; therefore, in the installation of new components, it may be necessary to rebalance the wheels with the tires mounted. When checking tire pressure, examine the tires for wear, cuts, bruises, and slippage.

8.25 BATTERY SERVICE

Access to the 12-volt battery is obtained by raising the rear seat and removing the cover of the battery box. The plastic battery box has a drain tube which is normally closed off with a cap and which should be opened occasionally to drain off any accumulation of liquid.

The battery should be checked for proper fluid level. DO NOT fill the battery above the baffle plates. DO NOT fill the battery with acid - use only water. A hydrometer check will determine the percent of charge in the battery.

If the battery is not up to charge, recharge starting at a 4 amp rate and finishing with a 2 amp rate. Quick charges are not recommended.

8.27 CLEANING

(a) Cleaning Engine Compartment

Before cleaning the engine compartment, place a strip of tape on the magneto vents to prevent any solvent from entering these units.

- (1) Place a large pan under the engine to catch waste.
- (2) With the engine cowling removed, spray or brush the engine with solvent or a mixture of solvent and degreaser. In order to remove especially heavy dirt and grease deposits, it may be necessary to brush areas that were sprayed.

CAUTION

Do not spray solvent into the alternator, vacuum pump, starter, or air intakes.

- (3) Allow the solvent to remain on the engine from five to ten minutes. Then rinse the engine clean with additional solvent and allow it to dry.

CAUTION

Do not operate the engine until excess solvent has evaporated or otherwise been removed.

- (4) Remove the protective tape from the magnetos.
- (5) Lubricate the controls, bearing surfaces, etc., in accordance with the Lubrication Chart.

(b) Cleaning Landing Gear

Before cleaning the landing gear, place a plastic cover or similar material over the wheel and brake assembly.

- (1) Place a pan under the gear to catch waste.
- (2) Spray or brush the gear area with solvent or a mixture of solvent and degreaser, as desired. Where heavy grease and dirt deposits have collected, it may be necessary to brush areas that were sprayed, in order to clean them.
- (3) Allow the solvent to remain on the gear from five to ten minutes. Then rinse the gear with additional solvent and allow to dry.
- (4) Remove the cover from the wheel and remove the catch pan.
- (5) Lubricate the gear in accordance with the Lubrication Chart.

(c) Cleaning Exterior Surfaces

The airplane should be washed with a mild soap and water. Harsh abrasives or alkaline soaps or detergents could make scratches on painted or plastic surfaces or could cause corrosion of metal. Cover areas where cleaning solution could cause damage. To wash the airplane, use the following procedure:

- (1) Flush away loose dirt with water.
- (2) Apply cleaning solution with a soft cloth, a sponge or a soft bristle brush.
- (3) To remove exhaust stains, allow the solution to remain on the surface longer.
- (4) To remove stubborn oil and grease, use a cloth dampened with naphtha.
- (5) Rinse all surfaces thoroughly.
- (6) Any good automotive wax may be used to preserve painted surfaces. Soft cleaning cloths or a chamois should be used to prevent scratches when cleaning or polishing. A heavier coating of wax on the leading surfaces will reduce the abrasion problems in these areas.

(d) Cleaning Windshield and Windows

- (1) Remove dirt, mud and other loose particles from exterior surfaces with clean water.
- (2) Wash with mild soap and warm water or with aircraft plastic cleaner. Use a soft cloth or sponge in a straight back and forth motion. Do not rub harshly.
- (3) Remove oil and grease with a cloth moistened with kerosene.

CAUTION

Do not use gasoline, alcohol, benzene, carbon tetrachloride, thinner, acetone, or window cleaning sprays.

- (4) After cleaning plastic surfaces, apply a thin coat of hard polishing wax. Rub lightly with a soft cloth. Do not use a circular motion.
- (5) A severe scratch or mar in plastic can be removed by rubbing out the scratch with jeweler's rouge. Smooth both sides and apply wax.

(e) Cleaning Headliner, Side Panels and Seats

- (1) Clean headliner, side panels, and seats with a stiff bristle brush, and vacuum where necessary.
- (2) Soiled upholstery, except leather, may be cleaned with a good upholstery cleaner suitable for the material. Carefully follow the manufacturer's instructions. Avoid soaking or harsh rubbing.

CAUTION

Solvent cleaners require adequate ventilation.

- (3) Leather should be cleaned with saddle soap or a mild hand soap and water.

(f) Cleaning Carpets

To clean carpets, first remove loose dirt with a whisk broom or vacuum. For soiled spots and stubborn stains use a nonflammable dry cleaning fluid. Floor carpets may be removed and cleaned like any household carpet.

8.29 WINTERIZATION

For winter operation a winterization plate is installed on the inlet opening of the oil cooler. This plate should be installed whenever the ambient temperature reaches 50°F or less. The plate should be removed and stored in the cockpit when the ambient temperature exceeds 50°F.

Section 9.

TS

	Page No.
General	9-1
Auto Flight H	9-3
Auto Control IIB	9-5
Electric Pitch	9-9

SECTION 9
SUPPLEMENTS

9.1 GENERAL

This section provides information in the form of Supplements which are necessary for efficient operation of the airplane when equipped with one or more of the various optional systems and equipment not provided with the standard airplane.

All of the Supplements provided by this section are "FAA Approved" and consecutively numbered as a permanent part of this Handbook. The information contained in each Supplement applies only when the related equipment is installed in the airplane.

THIS PAGE INTENTIONALLY LEFT BLANK

SUPPLEMENT 1

AUTOFLITE II AUTOPILOT INSTALLATION

SECTION 1 - GENERAL

This supplement supplies information necessary for the operation of the airplane when the optional AutoFlite II Autopilot is installed. The information contained within this supplement is to be used in conjunction with the complete handbook.

This supplement has been "FAA Approved" as a permanent part of this handbook and must remain in this handbook at all times when the optional AutoFlite II Autopilot is installed.

SECTION 2 - LIMITATIONS

- (a) Autopilot use prohibited above 155 KIAS.
- (b) Autopilot "OFF" during takeoff and landing.

SECTION 3 - EMERGENCY PROCEDURES

- (a) In case of malfunction PRESS disconnect switch on pilot's control wheel.
- (b) Rocker switch on instrument panel "OFF."
- (c) Unit may be overpowered manually at either control wheel.
- (d) In climb, cruise or descent configuration a malfunction with a 3 second delay in recovery initiation may result in 60° bank and 320' altitude loss. Maximum altitude loss measured at 155 KIAS in a descent.
- (e) In approach configuration a malfunction with a 1 second delay in recovery initiation results in 15° bank and 20' altitude loss.

SECTION 4 - NORMAL PROCEDURES

- (a) Engagement
 - (1) Rocker Switch on instrument panel - ON.
 - (2) Disconnect Switch on left hand side of pilot's control wheel - RELEASED.
- (b) Disengagement
 - (1) Depress Disconnect Switch on pilot's control wheel (or)
 - (2) Rocker Switch on instrument panel - OFF.
- (c) Heading Changes
 - (1) Depress Disconnect Switch, make Heading Change, release Disconnect Switch.
 - (2) Move Trim Knob on instrument for Drift Correction from a constant heading.
 - (3) Move Turn Command Knob on instrument for right or left banked turns.

(d) OMNI Tracker

- (1) Center Turn Command Knob and push IN to engage Tracker.
- (2) Trim Knob - push IN for high sensitivity.

SECTION 5 - PERFORMANCE

No changes to the basic performance provided by Section 5 of this Pilot's Operating Handbook are necessary for this supplement.

SUPPLEMENT 2

AUTOCONTROL IIIB AUTOPILOT INSTALLATION

SECTION 1 - GENERAL

This supplement supplies information necessary for the operation of the airplane when the optional Piper AutoControl IIIB Autopilot is installed. The information contained within this supplement is to be used in conjunction with the complete handbook.

This supplement has been "FAA Approved" as a permanent part of this handbook and must remain in this handbook at all times when the optional Piper AutoControl IIIB Autopilot is installed.

SECTION 2 - LIMITATIONS

- (a) Autopilot use prohibited above 126 KIAS.
- (b) Autopilot "OFF" during takeoff and landing.

SECTION 3 - EMERGENCY OPERATION

- (a) In an emergency the AutoControl IIIB can be disconnected by pushing the A/P ON-OFF Switch OFF.
- (b) The autopilot can be overpowered at either control wheel.
- (c) An autopilot runaway, with a 3 second delay in the initiation of recovery while operating in a climb, cruise or descending flight, could result in a 60° bank and 100' altitude loss.
- (d) An autopilot runaway, with a 1 second delay in the initiation of recovery, during an approach operation, coupled or uncoupled, could result in a 10° bank and 10' altitude loss.

SECTION 4- NORMAL PROCEDURES

PREFLIGHT

- (a) **AUTOPILOT**
 - (1) Place Radio Coupler in "HDG" Mode and place the A/P "ON-OFF" switch to the "ON" position to engage roll section. Rotate roll command knob left and right and observe that control wheel describes a corresponding left and right turn, then center knob.
 - (2) Set correct compass heading on D.G. and turn HDG bug to aircraft heading. Engage "HDG" mode switch and rotate HDG bug right and left. Aircraft control wheel should turn same direction as bug. While D.G. bug is set for a left turn, grasp control wheel and override the servo to the right. Repeat in opposite direction for right turn.

- (3) Tune and identify VOR or VOT station. Position Radio Coupler to OMNI Mode. Engage Autopilot ROLL and HDG switches. Set HDG bug to aircraft heading and rotate O.B.S. to cause OMNI indicator needle to swing left and right slowly. Observe that control wheel rotates in direction of needle movement.
- (4) Disengage A/P "ON-OFF" switch. Reset Radio Coupler control to HDG.

IN-FLIGHT

- (a) Trim airplane (ball centered).
- (b) Check air pressure vacuum to ascertain that the directional gyro and attitude gyro are receiving sufficient air.
- (c) Roll Section.
 - (1) To engage, center ROLL knob, push A/P "ON-OFF" switch to "ON" position. To turn, rotate console ROLL knob in desired direction. (Maximum angle of bank should not exceed 30°.)
 - (2) For heading mode, set directional gyro with magnetic compass. Push directional gyro HDG knob in, rotate bug to aircraft heading. Push console heading (HDG) switch to "ON" position. To select a new aircraft heading, push D.G. heading knob "IN" and rotate, in desired direction of turn, to the desired heading.

NOTE

In HDG mode the maximum bank angles are limited to approximately 20° and single command, heading changes should be limited to 150° (HDG bug not more than 150° from actual aircraft heading).

- (d) VOR
To Intercept:
 - (1) Using OMNI Bearing Selector, dial desired course inbound or outbound.
 - (2) Set identical heading on Course Selector D.G.
 - (3) After aircraft has stabilized, position coupler mode selector knob to OMNI mode. As aircraft nears selected radial, interception and crosswind correction will be automatically accomplished without further switching.

NOTE

If aircraft position is less than 45° from selected radial, aircraft will intercept before station. If position is more than 45°, interception will occur after station passage. As the aircraft nears the OMNI station, (1/2 nautical mile) the zone of confusion will direct an "S" turn in alternate directions as the OMNI indicator needle swings. This alternate banking limited to the standard D.G. bank angle, is an indication of station passage.

To Select New Course:

- (1) To select a new course or radial, rotate the HDG bug to the desired HDG (match course).
- (2) Rotate OBS to the new course. Aircraft will automatically turn to the intercept heading for the new course.

To Change Stations:

- (1) If same course is desired, merely tune receiver to new station frequency.
- (2) If different course is desired, position coupler mode selector to HDG mode. Dial course selector D.G. to new course. Dial OBS to new course and position coupler mode selector to OMNI mode.

(e) VOR Approach

Track inbound to station as described in VOR navigation section. After station passage:

- (1) Dial outbound course on Course Selector D.G., then dial same course on OBS.
- (2) After established on outbound radial, position coupler mode selector to HDG mode and select outbound procedure turn heading. After 40 seconds to 1 minute select a turn in the desired direction with the Course Selector D.G. to the inbound procedure turn heading.
- (3) Set OBS to inbound course.
- (4) When aircraft heading is 45° to the inbound course, dial Course Selector D.G. to inbound course and position coupler mode selector to OMNI mode.

NOTE

For precise tracking over OMNI station, without "S" turn, position coupler mode selector to HDG mode just prior to station passage. If holding pattern is desired, position coupler mode selector to HDG mode at station passage inbound and select outbound heading in direction of turn. After elapsed time, dial inbound course on Course Selector D.G. When aircraft heading is 45° to radial, position coupler mode selector to OMNI mode.

(f) LOC Approach Only

- (1) To intercept dial ILS outbound course on Course Selector D.G. When stabilized, position coupler mode selector to LOC REV mode.
- (2) After interception and when beyond outer marker, position coupler mode selector to HDG mode and dial outbound procedure turn heading. After one minute, dial inbound procedure turn heading in direction of turn.
- (3) When aircraft heading is 45° to ILS inbound course dial inbound course on Course Selector D.G. and position coupler mode selector to LOC NORM mode.
- (4) At the missed approach point (M.A.P.), or when missed approach is elected, position coupler mode selector to HDG mode and execute missed approach procedure.

(g) LOC Approach - Back Course (Reverse)

- (1) To intercept dial ILS Back Course outbound heading on Course Selector D.G. When stabilized, position coupler mode selector to LOC NORM mode.
- (2) After interception and when beyond fix, position coupler mode selector to HDG and dial outbound procedure turn heading. After one minute, dial inbound procedure turn heading in direction of turn.
- (3) When heading 45° to inbound course, dial inbound course on Course Selector D.G. and position coupler mode selector to LOC REV mode.
- (4) Approximately 1/2 nautical mile from runway, position coupler mode selector to HDG mode to prevent "S" turn over ILS station near runway threshold.
- (5) Missed approach - same as Front Course. (See (f) (4)).

SECTION 5 - PERFORMANCE

No changes to the basic performance provided by Section 5 of this Pilot's Operating Handbook are necessary for this supplement.

SUPPLEMENT 3

PIPER ELECTRIC PITCH TRIM

SECTION 1 - GENERAL

This supplement supplies information necessary for the operation of the airplane when the optional Piper Electric Pitch Trim is installed. The information contained within this supplement is to be used in conjunction with the complete handbook.

This supplement has been "FAA Approved" as a permanent part of this handbook and must remain in this handbook at all times when the optional Piper Electric Pitch Trim is installed.

SECTION 2 - LIMITATIONS

No changes of the basic limitations provided by Section 2 of this Pilot's Operating Handbook are necessary for this supplement.

SECTION 3 - EMERGENCY PROCEDURES

- (a) In case of malfunction, disconnect electric pitch trim by pushing pitch trim switch on instrument panel to OFF position.
- (b) In an emergency, electric pitch trim may be overpowered using manual pitch trim.
- (c) In cruise configuration, malfunction results in 10° pitch change and 200 ft altitude variation.
- (d) In approach configuration, a malfunction can result in a 5° pitch change and 50 ft altitude loss.

SECTION 4 - NORMAL PROCEDURES

The electric trim system may be turned ON or OFF by a switch located above the ignition switch. The pitch trim may be changed when the electric trim system is turned on either by moving the manual pitch trim control wheel or by operating the trim control switch on the pilot's control yoke.

SECTION 5 - PERFORMANCE

No changes to the basic performance provided by Section 5 of this Pilot's Operating Handbook are necessary for this supplement.

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 10

SAFETY TIPS

Paragraph No.		Page No.
10.1	General	10-1
10.3	Safety Tips	10-1

**SECTION 10
OPERATING TIPS**

10.1 GENERAL

This section provides operating tips of particular value in the operation of the Cherokee Warrior.

10.3 OPERATING TIPS

- (a) Learn to trim for takeoff so that only a very light back pressure on the control wheel is required to lift the airplane off the ground.
- (b) The best speed for takeoff is about 55 KIAS under normal conditions. Trying to pull the airplane off the ground at too low an airspeed decreases the controllability of the airplane in the event of engine failure.
- (c) Flaps may be lowered at airspeeds up to 103 KIAS. To reduce flap operating loads, it is desirable to have the airplane at a slower speed before extending the flaps. The flap step will not support weight if the flaps are in any extended position. The flaps must be placed in the "UP" position before they will lock and support weight on the step.
- (d) Before attempting to reset any circuit breaker, allow a two to five minute cooling off period.
- (e) Before starting the engine, check that all radio switches, light switches and the pitot heat switch are in the off position so as not to create an overloaded condition when the starter is engaged.
- (f) Strobe lights should not be operating when flying through overcast and clouds, since reflected light can produce special disorientation. Do not operate strobe lights when taxiing in the vicinity of other aircraft.
- (g) The rudder pedals are suspended from a torque tube which extends across the fuselage. The pilot should become familiar with the proper positioning of his feet on the rudder pedals so as to avoid interference with the torque tube when moving the rudder pedals or operating the toe brakes.
- (h) In an effort to avoid accidents, pilots should obtain and study the safety related information made available in FAA publications such as regulations, advisory circulars, Aviation News, AIM and safety aids.

- (i) The shape of the wing fuel tanks is such that in certain maneuvers the fuel may move away from the tank outlet. If the outlet is uncovered, the fuel flow will be interrupted and a temporary loss of power may result. Pilots can prevent inadvertent uncovering of the outlet by avoiding maneuvers which could result in uncovering the outlet.

Extreme running turning takeoffs should be avoided as fuel flow interruption may occur.

Prolonged slips or skids which result in excess of 2000 ft. of altitude loss, or other radical or extreme maneuvers which could cause uncovering of the fuel outlet must be avoided as fuel flow interruption may occur when tank being used is not full.

PILOT'S GUIDE KING KX 155/165 SILVER CROWN NAV/COMM SYSTEMS




King Radio Corporation, 400 North Rogers Road, Olathe, Kansas 66062 • (913) 782-0400 • TELEX WUD
(0) 4-2299 • CABLE: KINGRAD

King Radio S.A., P.O.B. No. 6, 80 Ave. Louis Casai, 1216 Cointrin • Geneva, Switzerland • Tel. Geneva 98 58 80
• TELEX 289445 KING CH • CABLE: KINGRADIO



HOW TO OPERATE THE KING KX 155/165 VHF NAV/COMM:



TURN-ON: Rotate the ON/OFF/Volume Control knob clockwise from the detented "OFF" position. Power will be activated and the unit will be ready to operate. No warm up time is required.

A non-volatile memory stores the "active" and "standby" frequencies during power shutdown. So, when turned on, the "USE" and "STBY" windows will display the same frequencies that were selected before shutdown.

The KX 165's digital "Radial" readout will only function when receiving a valid VOR signal.

NOTE: As with all avionics, the KX 155/165 should be turned on only after engine start-up. This is a simple precaution which will help protect the solid-state circuitry and extend the operating life of your avionics equipment.

To Communicate:

FREQUENCY SELECTION: By rotating the concentric COMM frequency selector knobs either clockwise or counterclockwise, the desired operating frequency can be entered into the "STBY" display window. A clockwise rotation of the knobs will increase the displayed frequency number, while a counterclockwise rotation will decrease it. The outer, larger selector knob is used to change the MHz portion of the frequency display; the smaller knob changes the kHz portion. This smaller knob is designed to change the indicated frequency in steps of 50 kHz when it is pushed in, and in 25 kHz steps when it is pulled out. At either band-edge of the 118.000—135.975 MHz frequency spectrum, an off-scale rotation will wrap the display around to the other frequency band-edge (i.e., 135.00 MHz advances to 118.00 MHz).

COMM CHANNELING: To tune the COMM transceiver to the desired operating frequency, the selected frequency must first be entered into the "STBY" display window and then activated by pushing the "flip-flop" transfer button. This will interchange the frequencies in the "USE" and "STBY" displays, and the transceiver will be tuned to the operating frequency appearing in the "USE" display.

As you can see, this feature makes it possible to display two COMM frequencies—one each in the "USE" and "STBY" displays—and then switch back and forth between them just by pressing the transfer button. An additional transfer button may also be remote mounted in the aircraft.


TRANSMIT INDICATOR: Whenever the microphone is keyed, a lighted "T" will appear between the "USE" and "STBY" displays to indicate that the transceiver is operating in the transmit mode.

VOLUME ADJUSTMENT TEST: To override the automatic squelch for audio test, or to aid in receiving a distant station, simply pull the volume control knob out and rotate to the desired listening level. Push the knob back in to activate the automatic squelch.

To Navigate:

NAV FREQUENCY SELECTION: By rotating the concentric NAV frequency selector knobs either clockwise or counterclockwise, the desired operating frequency can be entered into the "STBY" display window. A clockwise rotation will increase the displayed frequency number, while a counterclockwise rotation will decrease it. As with the COMM frequency selectors, an off-scale rotation of the NAV frequency band-edge (108.00 to 117.95) will wrap the display around to the other edge of the frequency band (i.e., 117.00 advances to 108.00 with MHz knob rotation). Remote DMF and internal glideslope channeling are also controlled by these selector knobs.

VOR ("RADIAL") MODE: When the smaller NAV kHz frequency selector knob is pulled out on the KX 165 model, the VOR Radial FROM the station in "USE" is digitally displayed in the "STBY/RAD" window. The "STBY" frequency will go into non-displayed storage from which it can be "flip-flopped" into "USE" at a press of the transfer button—without disturbing the displayed Radial. While in the "RADIAL" mode, rotation of the frequency selector knobs will channel the active frequency directly in the "USE" window display. If the VOR signal is too weak to provide a Radial readout, a "warning flag" is activated consisting of three dashes "---" displayed in the "STBY/RAD" window. Also, when an ILS frequency has been selected, the digital flag "---" will appear in the "STBY/RAD" window. This digital "RADIAL" mode is not provided on the lower-cost KX 155 model.



NAV FREQUENCY OPERATION: To tune the NAV receiver to the desired operating frequency, the selected frequency is first entered into the "STBY" display and then "flip-flopped" into "ACTIVE" status by pushing the transfer button.

IDENT: The NAV "IDENT" knob is activated by pulling it outward, so that both voice and ident can be heard. When this knob is pushed in, the ident tone is muted. Volume of voice/ident can be adjusted by turning this knob—clockwise to increase, counterclockwise to decrease.



The elapsed timer also has a "count-down" mode. To enter the countdown mode, the SET/RST button is depressed for about two seconds, or until the "ET" annunciation begins to flash. It is now in the ET set mode, and a time up to 59 minutes, 59 seconds may be preset into the elapsed timer with the concentric knobs. The preset time will be displayed and remain unchanged until SET/RST is pressed again, which will start the elapsed timer counting down from the preset number. When the timer reaches :00 it will start to count up as the display flashes for 15 seconds and an aural alarm, if installed, is activated for about 1 second.

NOTE: The standby frequency which is in memory while flight time or elapsed time modes are being displayed may be called back by pressing the FRQ button, then transferred to active use by pressing the FRQ button again.

While FLT or ET is displayed the "in use" frequency on the left side of the window may be changed, by using the frequency select knobs, without any effect on the stored standby frequency or the other modes. This feature is especially useful when searching for stations with unknown frequencies.

ERRONEOUS ADF BEARINGS DUE TO RADIO FREQUENCY PHENOMENA

Station Overlap

In the U.S., the FCC, which assigns AM

radio frequencies, occasionally will assign the same frequency to more than one station in an area. Certain conditions, such as Night Effect, may cause signals from such stations to overlap. This should be taken into consideration when using AM broadcast stations for navigation.

Sunspots and atmospheric phenomena may occasionally distort reception so that signals from two stations on the same frequency will overlap. For this reason it is always wise to make positive identification of the station being tuned, by switching the function selector to ANT and listening for station call letters.

Electrical Storms

In the vicinity of electrical storms, an ADF Indicator pointer tends to swing from the station tuned toward the center of the storm. Location of the storm can be useful information, but the erratic behavior of the pointer should be taken into account.

Night Effect

This is a disturbance particularly strong just after sunset and just after dawn. An ADF indicator pointer may swing erratically at these times. If possible, tune to the most powerful station at the lowest frequency. If this is not possible, take the average of pointer oscillations to determine relative station bearing.

Mountain Effect


Radio waves reflecting from the surface of mountains may cause the pointer to fluctuate or show an erroneous bearing. This should be taken into account when taking bearings over mountainous terrain.

Coastal Refraction

Radio waves may be refracted when passing from land to sea or when moving parallel to the coastline. This also should be taken into account.

PILOT'S GUIDE

THE KING KR 87 ADF SYSTEM





Tomorrow's Avionics Today ... from KING of course.

King Radio Corporation, 400 North Rogers Road, Olathe, Kansas 66062 • (913) 782-0400 • TELEX WUD (0) 4-2299 • CABLE: KINGRAD


King Radio S.A., P.O.B. No. 6, 80 Ave. Louis Casai, 1216 Cointrin —Geneva, Switzerland • Tel. Geneva 98 58 80 • TELEX 289445 KING CH • CABLE: KINGRADIO

OPERATING INSTRUCTIONS




KI 227
KI 227-00 shown, slaved
KI 227-01 also available

—“SYNC” knob




KI 228

Slaved KI 228-01 shown. Standard KI 228-00 also available with manually rotatable compass card.



KI 229



KNI 582

TURN-ON

Rotate the ON/OFF/VOL knob clockwise from the detented “OFF” position. The unit will be activated and will be ready to operate. Rotation of this control also adjusts audio volume. The KR 87 has “audio muting” which causes the audio output to be muted unless the receiver is locked on a valid station.

FREQUENCY SELECTION

The active frequency (to which the ADF is tuned) is displayed in the left side of the window at all times. A standby frequency is displayed in the right side when “FRQ” is annunciated. The standby frequency is placed in “blind” memory when either FLT (Flight Time) or ET (Elapsed Time) mode is selected.

With “FRQ” annunciated, the standby frequency is selected using the frequency select knobs which may be rotated either clockwise or counter clockwise. Pull the small inner knob out to tune 1’s. Push the small inner knob in to tune 10’s. The outer knob tunes the 100’s and the 1000’s up to 1799.

The standby frequency selected may then be put into the active window by pressing the “FRQ” button. The standby and active frequencies will be exchanged (flip-flopped) and the new frequency will become active, and the former active frequency will go into standby.

OPERATING MODES



Antenna (ANT) mode is selected and annunciated when the “ADF” button is in the “out” position. ANT provides improved audio reception from the station tuned and is usually used for identification. The bearing pointer in the KI 227 indicator will be deactivated and immediately turn to the 90° relative position and remain there during ANT reception.



The ADF mode is selected and annunciated when the “ADF” button is in the depressed position. ADF activates the bearing pointer in the KI 227 indicator, causing it to move without hesitation to point in the direction of the station relative to the aircraft heading. The compass card on the KI 227 may be rotated as desired by using the heading knob.

NOTE: The KI 227-01 or KI 228-01 indicators, when installed with a King KCS 55A Compass System, have a slaved compass card. Magnetic heading of the aircraft will be under the lubber line. The indication of this

compass card should be compared with that of the KI 525A magnetic indicator from time to time. Check especially after steep bank turns and taxi turns. If a discrepancy between the two readings exists, the KI 227-01 or KI 228-01 compass card should be synchronized to the KI 525A compass card by rotating the “SYNC” knob on the indicator.



Outside of the United States some stations are unmodulated and use an interrupted carrier for identification purposes. The BFO mode, activated and annunciated when the “BFO” button is depressed, permits the carrier wave and the associated morse code identifier broadcast on the carrier wave to be heard.

ADF TEST (PRE-FLIGHT OR IN-FLIGHT)

Select ANT mode. This will cause the bearing pointer to move directly to the parked 90° position. Make sure the unit is tuned to a usable frequency. Now select ADF mode and the needle should move without hesitation to the station bearing. Excessive sluggishness, wavering or reversals indicate a signal that is too weak or a system malfunction.

OPERATING THE TIMERS

The flight timer will always be automatically reset to :00 whenever power is interrupted either by the avionics master switch or the unit’s ON/OFF switch. An optional external switch may be installed which, when activated, will stop or start the flight timer. This switch would be of use during a non-refueling stop when resetting the flight timer is not desired. On some aircraft it may be desirable to use the aircraft strut switch instead of a manual switch to stop and start the flight timer. It should be emphasized that the start/stop function will only operate with power applied to the unit. Always read flight time prior to power shutdown.



Flight time or elapsed time are displayed and annunciated alternatively by depressing the FLT/ET button. The flight timer continues to count up until the unit is turned off, (stopped with an external switch) or reset. The elapsed timer may be reset back to :00 by pressing the SET/RST button. It will then start counting up again. (NOTE: pressing the SET/RST button will reset the elapsed timer whether it is being displayed or not)

STC MOD FACT SHEET

Models: All Piper PA-24 Comanche
PA-28 Series
PA-30 Twin Comanche
PA-32 Series
PA-34 Seneca
PA-39 Twin Comanche
PA-44 Seminole



Purpose: Increases Side Window Thickness for a Quieter Cabin

Models / Part Numbers:

Piper PA-24 Comanche
Piper PA-28 Seriese
Piper PA-30 Twin Comanchee
Piper PA-32 Seriese
Piper PA-34 Seneca, Seneca II, Seneca IIIe
Piper PA-39 Twin Comanchee
Piper PA-44 Seminole


See Catalog for Part Numbers. Most STC Extra-Thick Windows will have a .xxx thickness suffix, such as 401.125, 769.250, etc.

The Original Design: The original windows were either 5/64" (.080") or 1/8" (.125") thick. Some aircraft were also equipped with double pane windows, the inner pane being .040" or .060" thick.

The LP Aero Plastics, Inc. Mod: This STC allows 1/8" (.125), 3/16" (.187"), or 1/4" (.250") side windows to be installed in all models. The thicker windows are more rigid and therefore resonate less, transmitting less noise into the cabin. They install exactly as do the original windows with the extra thickness being accommodated by moving the retainer angles and screws inward (see figure 1). If double pane windows were originally installed, the STC thicker windows will eliminate the inner panes, and relocation of the retainer angles may not be necessary.

Competitive Information: No other company offers STC Extra-Thick Side Windows for these aircraft.

Options Available: Thicknesses of 1/8", 3/16", and 1/4" are available, along with Clear, Green, or Solar Gray Tints.



[\[Home\]](#) [\[Back to STC Index\]](#) [\[Catalog Index\]](#) [\[E-mail\]](#)



The World's Largest Manufacturer of Light Aircraft Windshields and Windows

AIRCRAFT WINDSHIELD AND WINDOW CARE AND MAINTENANCE

You can keep your aircraft windshield and windows looking and performing like new by using the proper care products and techniques, and by understanding a little about the material you are working with.

First, most aircraft windows are acrylic plastic (as opposed to "Lexan" or polycarbonate), and acrylic plastic is scratchable. Proper care involves preventing scratches that are preventable and properly taking care of those that are not.

When cleaning a window, always remove as much abrasive dirt as possible without touching the surface. Ideally this would involve flushing the surface with water and allowing the accumulated bug residue to soak, possibly with a little dish washing liquid added to the water. If a little rubbing is needed, do it lightly with your bare hand. After a final flushing with more water and carefully drying with a clean soft cloth, use a good grade cleaner/polish intended for acrylic windows, following the manufacturers directions.

We need to step back here and take a look at cleaner/polishes. Everybody seems to have a favorite, from great and proper to poor and very dangerous. The good ones, at least those that are safe to use on acrylic plastics, tend to be the commercial ones, intended to be used on this specific material. The bad ones, including the very dangerous, tend to be materials never intended to be used as an aircraft window cleaner/polish, such as glass cleaners and furniture polish. Glass cleaners invariably contain ammonia, a killer of acrylics. **DO NOT** use anything containing ammonia on acrylic plastics. It will cause crazing (thousands of microscopic cracks) in short order. Furniture polish seems to be safer, but its long term use is undocumented and reports indicate it builds up and produces smears that are hard to polish off. Something to consider about furniture polish - it is intended to be used indoors, not outdoors, and on furniture, not aircraft windows. Furthermore, it's not much less expensive than many aircraft window products.

Good and safe care products vary in their ease of use and other properties, so if you don't like what you're using, give another a try. Talk with other pilots about what they are using, but be sure the product you select is intended for acrylic windows. Other products to keep away from your windows include any aromatic solvent, such as methyl ethyl ketone, acetone, lacquer thinner, gasoline (a minor fuel spill should do no harm), and, heaven forbid, paint stripper. If you have to remove masking tape residue or other sticky or greasy stuff, the safest solvents are 100% mineral spirits or kerosene. Some alcohols are safe, such as isopropyl alcohol, but not all.

Concerning the polishing cloth, use the softest cotton cloth available. One hundred percent cotton flannel is ideal and available in yard goods stores. Old washed-out cotton T-shirts are a good second choice. We at LP Aero Plastics have never found a paper product that did not scratch, even those advertised for cleaning plastics. One benefit of cotton cloth is that it can be washed, thereby effectively recycling the material.

Your choice of cleaner/polish should also be based on what is needed. Basically, you have to determine what type of care is needed and pick the best products to do the job.

First, it's best to understand what types of products are available. They can be loosely grouped into three categories:

1. Non-abrasive liquid sprays, in pumps or aerosols, that may or may not have scratch filling properties.
2. Non-abrasive creams that have scratch filling properties.
3. Mildly-abrasive creams that have scratch removing properties.

Since windows do accumulate minute scratches as part of everyday life (the kind you can't feel with a fingernail but can really see when flying into the sun), the products that fill fine scratches are great for regular use. If scratches still appear when flying toward the sun, the abrasive variety and some elbow grease is called for. This type of cleaner should be used occasionally only as needed. Most manufacturers of abrasive cleaners recommend following up with a scratch filling product as a second step.

So what happens when you have scratches that you can't take care of with the above methods and perhaps you can feel with a fingernail? You have to get more aggressive. The danger, though, is in getting too aggressive.

Practically speaking, the only way to remove a scratch from clear acrylic is to remove material from around the scratch down to the greatest depth of the scratch, then polishing the window back to clarity. There are two problems with this process. First, polishing back to clarity can be a difficult process especially if you started with a coarser than necessary abrasive. Second, it is very easy to induce an annoying and possibly dangerous optical distortion if you have not worked evenly in a large enough area.

Keep in mind that some scratches are best left alone because sometimes the cure is worse than the ailment. But if you decide to proceed, the morals of the story are to have the patience to work with only the finest abrasive necessary to remove the scratch, and to work in a large enough area to prevent optical distortions. Also, be sure to practice on scrap material before you tackle a windshield or window.

The 3M Company, Meguiars, Micro-Surface (Micro-Mesh), and others all supply kits that will do this job - with lots of your help. The kits consist of many progressively finer abrasive sheets or creams that are used in sequence to remove defects and to polish back to clarity. Another product, our favorite, is the Satinal pad made by Transelco. This one-time-use pad is dipped in water and makes a 5-micron slurry that will remove fine scratches and polish back to clarity in one step. For deeper scratches, it can be used in conjunction with 600, 1500, or 2000 grit wet sandpaper. Again, it would be best to practice on scrap material. By now, you have figured out this can be a lot of work, and you're right.

Another consideration, especially on light aircraft, is the feasibility of trying to repair some windows. The windshield on the Cessna 150, for instance, is .125 (or 1/8") thick, and some Piper Cherokee rear windows are only .080 (or 5/64") thick. So when you start to remove material, you have to be aware of what you will have left structurally. Keep in mind that most repairable windows, such as those found on pressurized air liners, have published specifications for minimum allowable thickness. Most light aircraft have no such specification. Sometimes,

labor spent on a repair attempt would probably be better spent installing a new window.

Another word of caution. If you are working on a homebuilt with polycarbonate, or "Lexan," windows, there is no good way to remove scratches. Polycarbonate is so soft that any attempt to remove material by abrasion will do more harm than good. There are hard coated varieties of polycarbonate that are less scratchable, but trying to repair a scratch in these will only remove the hard coating. Your only option will be to fill minor scratches with a scratch-filling polish or replace the window.

OTHER CARE PROBLEMS

Occasionally, we hear reports of canopy covers and sun shields that do damage in ways that are surprising. Canopy covers, the ones that cover the outside of the windshield and windows, certainly have to be made of a soft material on the side that contacts the windows, but they must also be cinched down tight to prevent fluttering in the wind. Keep in mind that minute abrasive particles between the canopy cover and the windows are practically impossible to eliminate, and any movement of the cover grinds away at the windows.

Sun shields, the reflective curtains applied to the inside of the windshield and windows, sometimes have sharp metallic edges (especially the home made variety) that can scratch severely enough to warrant window replacement in short order. Trying to remove scratches from the inside of a sharply sloping windshield can be especially trying. But both canopy covers and sun shields can cause damage of a chemical nature also. Some plastics, especially vinyls, can release plasticizers that will attack acrylics. A common example of this type of reaction is a fresh photocopy placed inside a vinyl notebook with the ink touching the vinyl. Soon you have everything sticking together. On an aircraft, if you have a volatile plastic in close proximity to your windows and add the heat of the sun, you may soon have severely crazed and damaged windows.

Certainly not all canopy covers and sun shields cause this problem, but it is a good question to ask at purchase time. Just be sure you are not sacrificing your windshield and windows at the same time you are protecting the avionics and interior.

But for all that can go wrong and shorten the life of aircraft windshields and windows, many flying today are well over 20 years old. If properly installed and maintained, longevity can, and regularly is, attained. You need to understand the material and the processes, and the rest is easy.

[\[Home\]](#) [\[Back to Documentation\]](#) [\[E-mail\]](#)